



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		805884T	ALTERNATOR ASSEMBLY	1		
1	11	809136	NUT	1		
2	13	809137	LOCKWASHER	1		
3		889910	PULLEY	1		
4	23	809135	SPACER	1		
5		809139	FAN ASSEMBLY	1		
6	23	809140	SPACER	1		
7		809151	BRACKET ASSEMBLY-FRONT	1		
8	10	809154	SCREW	3		
9	30	809153	BEARING-BALL	1		
10		809152	RETAINER	1		
11		809150	ROTOR	1		
12		809133T	STATOR	1		
13		809155	BRACKET ASSEMBLY-REAR	1		
14		809162	RECTIFIER	1		
15	10	809160	SCREW-SET	1		
16		809146	MOLD	2		
17	11	809143	NUT	8		
18		809161	CONDENSER	1		
19		809158	MOLD	1		
20	11	809157	NUT	1		
21	25	809156	O-RING	1		
22	10	809159	BOLT	1		
23	10	809138	BOLT-THRU	4		
24		811883T	REGULATOR ASSEMBLY	1		
25		811884	BRUSH	2		
26	24	811885	SPRING	2		
27	10	809141	SCREW	2		
28		809142	TERMINAL	1		
29		809149	CAP-INSULATOR	2		
30		809144	COVER	1		
31	10	809145	SCREW-SET	1		
32	84	809148	LEAD WIRE (BLACK)	1		
33	84	809147	LEAD WIRE (RED)	1		