



A = FRONT COVER

Parts List

| Ref | Class | Part     | Description             | Qty | Comment | Footnote |
|-----|-------|----------|-------------------------|-----|---------|----------|
| 1   |       | 805884T  | ALTERNATOR              | 1   |         |          |
| 2   | 12    | 96457    | WASHER-PHENOLIC         | 1   |         |          |
| 3   | 13    | 26992    | LOCKWASHER (1/4 IN.)    | 1   |         |          |
| 4   | 11    | 94330    | NUT (1/4-20)            | 1   |         |          |
| 5   | 13    | 26996    | LOCKWASHER (#10)        | 2   |         |          |
| 6   | 11    | 79989    | NUT (#10-24)            | 2   |         |          |
| 7   |       | 806979T  | BRACKET-ALTERNATOR      | 1   |         |          |
| 8   | 10    | 854181   | SCREW (M8)              | 1   |         |          |
| 9   | 13    | 811460   | LOCKWASHER              | 1   |         |          |
| 10  | 11    | 854184   | NUT (M8)                | 1   |         |          |
| 11  | 10    | 855508   | SCREW (M14 X 25)        | 2   |         |          |
| 12  |       | 806980T  | BRACE                   | 1   |         |          |
| 13  | 10    | 35386    | SCREW (5/16-18 X 1 IN.) | 1   |         |          |
| 14  | 13    | 53166    | LOCKWASHER (5/16)       | 1   |         |          |
| 15  | 12    | 814806   | WASHER                  | 1   |         |          |
| 16  | 10    | 40003 82 | SCREW (M10 X 50)        | 1   |         |          |
| 17  | 23    | 807030   | SPACER                  | 1   |         |          |
| 18  | 12    | 811479   | WASHER                  | 1   |         |          |
| 19  | 11    | 40136 10 | NUT (M10)               | 1   |         |          |
| 20  | 57    | 64032A 1 | V BELT                  | 2   |         |          |