



2038

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	486	889864	CRANKSHAFT	1		1
2	28	801331642	KEY	1		
3	43	889865	GEAR-CRANKSHAFT	1		1
4	23	811376	BEARING	1	(STANDARD)	
4	23	811377	BEARING	AR	(.25MM)	
4	23	811378	BEARING	AR	(.50MM)	
5	23	801331631	BEARING	4	(STANDARD)	
5	23	801331632	BEARING	AR	(.25MM)	
5	23	801331633	BEARING	AR	(.50MM)	
6	23	803621	WASHER-FRONT THRUST	1		
6	23	884006	WASHER-FRONT THRUST	AR	(.10MM)	
6	23	884007	WASHER-FRONT THRUST	AR	(.20MM)	
7	23	803622	WASHER-REAR THRUST	1		
8	23	884023	BEARING	1	(STD)	
8	23	884024	BEARING	AR	(.25MM)	
8	23	884025	BEARING	AR	(.50MM)	
9		811379	FLANGE ASSEMBLY- FRONT	5		
10	17	801331647	PIN	10		
11	10	811382	SCREW (M10 X 90)	10		
12	13	809932110	LOCKWASHER	10		
13		854093	NOZZLE	6		
14		884026	FLANGE ASSEMBLY-REAR	1		
15	17	809941485	PIN	1		
16	16	811383	STUD (M8 X20)	6		
17	26	884027	SEAL	1		
18	25	801331654	O-RING	1		5
19	12	40022 17	WASHER	6		
20	13	811384	LOCKWASHER	6		
21	11	854037	NUT (M8)	6		
.	27	881742	OVERHAUL GASKET SET	1		