



ALTERNATOR

| Parts List | | | | | | |
|------------|-------|--------|----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 853257 | ALTERNATOR (65 Amp) | 1 | | |
| 1 | 390 | 7027 | NUT | 1 | | |
| 2 | 13 | 808542 | LOCKWASHER | 1 | | |
| 3 | | 853258 | PULLEY | 1 | | |
| 4 | 390 | 7004 | FAN | 1 | | |
| 5 | 390 | 7034 | KEY | 1 | | |
| 6 | | 813969 | SPACER | 1 | | |
| 7 | | 808527 | HOUSING-Front | 1 | | |
| 8 | 390 | 7007 | BEARING-Ball | 2 | | |
| 9 | 390 | 7006 | RING-Retaining (Front) | 1 | | |
| 10 | | 808528 | ROTOR | 1 | | |
| 11 | 390 | 7017 | RING-Retaining (Rear) | 1 | | |
| 12 | 390 | 7014 | RING-Slip | 1 | | |
| 13 | | 808529 | STATOR | 1 | | |
| 14 | 390 | 7009 | DIODE-Rectifier (Negative) | 1 | | |
| 15 | | 808531 | DIODE-Rectifier (Positive) | 1 | | |
| 16 | 390 | 7024 | INSULATOR | 2 | | |
| 17 | 12 | 813984 | WASHER | 1 | | |
| 18 | 11 | 808544 | NUT | 3 | | |
| 19 | 390 | 7020 | SLEEVE | 1 | | |
| 20 | 390 | 7023 | INSULATOR | 2 | | |
| 21 | | 808536 | SLEEVE | 1 | | |
| 22 | 390 | 7003 | HOUSING-Rear | 1 | | |
| 23 | 10 | 808535 | BOLT-Thru | 4 | | |
| 24 | | 808532 | BRUSH ASSEMBLY | 1 | | |
| 25 | 10 | 808540 | SCREW | 2 | | |
| 26 | 390 | 7013 | GASKET | 1 | | |
| 27 | 12 | 808537 | WASHER | 2 | | |
| 28 | 11 | 808539 | NUT | 2 | | |
| 29 | | 813972 | CAPACITOR | 1 | | |
| 30 | 13 | 26396 | LOCKWASHER | 3 | | |
| 31 | 11 | 808538 | NUT | 3 | | |
| 32 | | 808534 | VOLTAGE REGULATOR | 1 | | |
| 33 | 10 | 808541 | SCREW | 2 | | |
| 34 | | 808543 | CAP | 2 | | |
| - | | 808533 | DIODE FIELD | AR | | 13 |