



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-		831001671	STARTER ASSEMBLY	1	16
-		831001672	STARTER ASSEMBLY	1	16
42		831391040	LEADWIRE	1	
43		832191120	WASHER-Start	2	
44	11	832311040	NUT-Start	1	
45		831121720	BOLT-Housing Set	1	
46		832621100	HOLDER	1	
47		832481280	PLATE-Insl	1	
48		831591270	COVER-Magnet Switch	1	
49		831010060	NUT-Lock	1	(FOR ?831001672! STARTER)
50		832311030	NUT-Start	2	
51		838731380	WASHER	1	
52		835101174	O RING	1	
53		831201320	YOKE ASSEMBLY-Start	1	
54		838731380	WASHER	2	
55		832411020	WASHER-Contact Plate Lock	1	
56		831351210	BUSH-Terminal Insl	1	
57		835105107	O RING	1	
58		831251150	BUSH-Center Bearing	1	
59		831121660	BOLT-Housing Set	1	
60		832631090	PIN-Weight	1	
61		831121730	BOLT-Housing Set	8	
62		831211220	COIL-Start Field	1	
63		831351220	BUSH-Terminal Insl	1	
64		835110126	O RING	1	
65		831251140	BUSH-Center Bearing	1	
66		832191200	WASHER	1	
67		831121740	BOLT-Housing Set	1	
68		831381240	PACKING	1	
69		831121650	BOLT-Housing Set	2	
70		831391030	LEADWIRE	2	
71		831401240	HOLDER ASSEMBLY	1	(FOR ?831001671! STARTER)
71		831401241	HOLDER ASSEMBLY	1	(FOR ?831001672! STARTER)
72		831431120	SPRING-Start Brush	4	(FOR ?831001671! STARTER)
72	24	831431121	SPRING-Start Brush	4	(FOR ?831001672! STARTER)
73		831421240	BRUSH-Start	4	(FOR ?831001671! STARTER)
73		831421241	BRUSH-Start	4	(FOR ?831001672! STARTER)
74		834999962	PACKING	4	
75		832191170	WASHER-Start	2	
76		831111350	BOSH-Drive Housing	1	
77		831271100	FLY-DRIVE	1	