



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		831001751	TURBOCHARGER ASSEMBLY	1		
1		831501050	ROTOR ASSEMBLY	1		
2		831161020	SLINGER-OIL	1		
3		831421070	SPACER-Thrust	1		
4		831241190	SEAL	2		
5		831241170	SEAL	1		
6		831171140	NUT	1		
7		831181020	IMPELLER	1		
8		831141040	CASE-Compressor	1		
9		831231110	PLATE	3		
10		831451130	BOLT	6		
11	13	838006150	LOCKWASHER	6		
12		831111110	CASE-Hot Section	1		
13		831451100	BOLT	4		
14		831211040	CASE-Bearing	1		
15		831231120	PLATE	1		
16		831361070	SCREW	4		
17		831131160	PLATE-Lock	4		
18		831411030	SHIELD-Heat	1		
19		831131120	PLATE-Lock	4		
20		831361040	SCREW	4		
21		831271020	BACKING PLATE	1		
22		831311110	BUSHING	2		
23		831431040	BEARING-Thrust	1		