



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
39	12	835913110	WASHER	2		
40		838031080	SEPARATOR ASSEMBLY-Water	1	(SEE SEPARATOR ASSY - WAT	
40		838031160	SEPARATOR ASSEMBLY-Water	1	(SEE SEPARATOR ASSY - WAT	
41	12	836008180	WASHER	3		
42	32	838061440	HOSE ASSEMBLY-Fuel	1		
43	10	831110301	BOLT	2		
44		830101190	FILTER ASSEMBLY-Fuel	1	(SEE FILTER ASSEMBLY - FUEL	
45		835818171	PLATE-Caution	1		
46	32	838061370	HOSE ASSEMBLY-Fuel	1		
47	10	831914184	BOLT	2		
48	12	835914104	WASHER	4		
49	32	838063030	HOSE ASSEMBLY-Fuel	1		
50		836101150	NOZZLE AND HOLDER SET (175	6	-	
50		836101650	NOZZLE AND HOLDER SET (220	6	-	
51		836301080	HOLDER ASSEMBLY-Nozzle (17	6	(SEE HOLDER ASSEMBLY - NO:	
51		836301210	HOLDER ASSEMBLY-Nozzle (22	6	(SEE HOLDER ASSEMBLY - NO:	
52		836501100	NOZZLE ASSEMBLY (175 H.P.)	6	-	
52		836501550	NOZZLE ASSEMBLY (220 H.P.)	6	-	
53	25	836671031	RING-Packing	6		
54		839041250	CLIP ASSEMBLY	8		
55	32	837111660	PIPE-Injector (#1)	1		
56	32	837121650	PIPE-Injector (#2)	1		
57	32	837131590	PIPE-Injector (#3)	1		
58	32	837141620	PIPE-Injector (#4)	1		
59	32	837151640	PIPE-Injector (#5)	1		
60	32	837161580	PIPE-Injector (#6)	1		
61	32	837661260	PIPE-Through Feed	1		
62		839041090	CLIP ASSEMBLY	1		
63		833941580	BRACKET-Fuel Filter	1		
64	10	831108400	BOLT	1		
65	10	839108202	BOLT (220 H.P.)	1	-	
66		833941591	BRACKET-Fuel Filter	1		