



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		830124294	BOLT	1	
2	10	831110001	BOLT	1	
3	10	831110352	BOLT	1	
4	10	831910104	BOLT	1	
5		835910130	BOLT	1	
6		838012300	LOCKWASHER	1	
7		836012220	WASHER	1	
8	22	830235125	CONNECTOR PIPE	1	
9		834402531	O RING	2	
10		836911190	GASKET-Oil Filter	1	
11	25	834402135	O RING	3	
12		836002880	FILTER ASSEMBLY-Oil	1	(SEE FILTER ASSEMBLY - OIL)
13		835818181	PLATE-Caution	1	
14		830481160	BRACKET ASSEMBLY-Oil Pipe	1	
15	12	836010220	WASHER	4	
16	10	831110200	BOLT	1	
17		831041240	STRAINER ASSEMBLY-Oil	1	
18	10	839108162	BOLT	2	
19	25	834402135	O RING	2	
20		834111370	PIPE-Oil Inlet	1	
21	10	838108250	BOLT	4	
22	25	835125103	O RING	1	
23		838010250	LOCKWASHER	3	
24		830010080	NUT	1	
25	10	839108552	BOLT	2	
26	10	831110651	BOLT	2	
27		831101382	PUMP ASSEMBLY-Oil	1	(SEE PUMP ASSEMBLY - OIL)
28	10	831110401	BOLT	1	
29		832531050	GASKET-Oil Cooler Case	2	
30		837111210	CASE-Oil Cooler	1	
31	10	835908103	BOLT	2	
32	10	839108452	BOLT	7	
33	27	836925101	GASKET-Flange	1	
34	12	836008180	WASHER	2	
35	13	838008200	LOCKWASHER	2	
36	10	839008176	BOLT	2	
37		830872930	PIPE ASSEMBLY-Coolant By Pass	1	
38		836404420	CLAMP	2	
39	32	830234144	HOSE-Water	1	
40	10	839108652	BOLT	2	
41	10	839108800	BOLT	1	