

NO IMAGE

| Parts List |       |           |                              |     |                            |          |
|------------|-------|-----------|------------------------------|-----|----------------------------|----------|
| Ref        | Class | Part      | Description                  | Qty | Comment                    | Footnote |
| -          | 91    | 53459     | ROD TOOL                     | 1   |                            |          |
| -          | 91    | 61069T    | GEAR HOUSING COVER NUT TO    | 1   | (Standard Propshaft)       |          |
| -          | 91    | 90338A 1  | BEARING CARRIER PULLER       | 1   |                            |          |
| -          | 91    | 840393A 1 | PROPELLER SHAFT INSTALLATI   | 1   |                            |          |
| -          | 91    | 840393    | BEARING CARRIER RETAINER     | 1   | (Hi-Performance Propshaft) |          |
| -          | 91    | 840388    | BEARING CARRIER INSTALLAT    | 1   |                            |          |
| -          | 91    | 840385    | SEAL INSTALLATION TOOL       | 1   |                            |          |
| -          | 91    | 89867T    | BEARING DRIVER               | 1   |                            |          |
| -          | 91    | 813653T   | BEARING DRIVER               | 1   |                            |          |
| -          | 91    | 63638T    | BEARING DRIVER               | 1   |                            |          |
| -          | 91    | 43559T    | CLAMP PLATE                  | 1   |                            |          |
| -          | 91    | 89865     | CUP AND SEAL DRIVER          | 1   |                            |          |
| -          | 91    | 31106T    | MANDREL, Bearing Driver Cup  | 1   |                            |          |
| -          | 91    | 67443T    | CUP DRIVER                   | 1   |                            |          |
| -          | 91    | 58222A 1  | DIAL INDICATOR TOOL          | 1   |                            |          |
| -          | 91    | 83155     | ADAPTER KIT, Dial Indicator  | 1   |                            |          |
| -          | 91    | 61077T    | DRIVESHAFT ADAPTOR           | 1   |                            |          |
| -          | 91    | 37323     | DRIVER ROD                   | 1   |                            |          |
| -          | 91    | 18605A 2  | BEARING ADAPTOR INSTALLATI   | 1   |                            |          |
| -          | 91    | 42840T    | SHIMMING TOOL                | 1   |                            |          |
| -          | 91    | 34569A 1  | PULLER ASSEMBLY, Slide Hamme | 1   |                            |          |
| -          | 91    | 31229     | SHAFT                        | 1   |                            |          |
| -          | 91    | 66274     | TORQUE WRENCH, (0-150 lb-in) | 1   |                            |          |
| -          | 91    | 37241     | PULLER PLATE                 | 1   |                            |          |
| -          | 91    | 31229A 7  | PULLER KIT, Bearing          | 1   | (INCLUDES THE FOLLOWING IT |          |
| -          | 91    | 15755T    | MANDREL                      | 1   |                            |          |
| -          | 91    | 38628T    | INSTALLER TOOL, Bearing      | 1   |                            |          |
| -          | 91    | 30366T 1  | COLLAR                       | 1   |                            |          |
| -          | 91    | 32336     | DRIVER HEAD                  | 1   |                            |          |
| -          | 91    | 36569T    | DRIVEHEAD TOOL               | 1   |                            |          |
| -          | 91    | 37311     | DRIVER HEAD                  | 1   |                            |          |
| -          | 91    | 37312T    | DRIVER HEAD                  | 1   |                            |          |
| -          | 91    | 52393T    | DRIVER HEAD                  | 1   |                            |          |
| -          | 91    | 37323     | DRIVER ROD                   | 1   |                            |          |
| -          | 11    | 24156     | NUT, (.625-18)               | 1   |                            |          |
| -          | 91    | 36571T    | DRIVESHAFT BEARING WRENI     | 1   |                            |          |
| -          | 91    | 37324T    | PILOT WASHER                 | 1   |                            |          |
| -          | 91    | 37350T    | MANDREL                      | 1   |                            |          |
| -          | 91    | 29310     | PLATE                        | 1   |                            |          |
| -          | 91    | 36379     | PULLER HEAD                  | 1   |                            |          |
| -          | 91    | 22225T    | DRIVER HEAD                  | 1   |                            |          |