



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1547	2024A 1	DRIVE SHAFT HOUSING ASSEMBLY	1		
1	1547	2096A 1	DRIVE SHAFT HOUSING ASSEMBLY	1		
1	1547	2184A 1	DRIVE SHAFT HOUSING ASSEMBLY	1		
2	23	32632	BUSHING, DRIVE SHAFT HOUSING	1,1,1,1		
3	22	31704	PLUG, PIPE - DRIVE SHAFT HOUSING	1,1,1,1		
4	19	32652	WELCH PLUG, DRIVE SHAFT HOUSING	1,1,1,1		
5	16	30929	STUD, DRIVE SHAFT HOUSING	2,2,2,2		
6	27	32599	GASKET, DRIVE SHAFT HOUSING	2		
6	27	33507	GASKET, DRIVE SHAFT HOUSING	1		
6	27	33796	GASKET, DRIVE SHAFT HOUSING	1,1		
7	10	32515	SCREW, DRIVE SHAFT HOUSING	6,6		
7	10	33811	SCREW, DRIVE SHAFT HOUSING	6,6	NOTE) B-10-33811 SCREW (6) AT SERIAL 00000000-01536617	
8	12	32648	WASHER, DRIVE SHAFT HOUSING	6,6	SERIAL 00000000-01536617	
8	12	34567	WASHER, DRIVE SHAFT HOUSING	6,6	SERIAL 01536618-01684187	
9	11	22178	NUT, DRIVE SHAFT HOUSING TO DRIVE	6,6		
10		32589	ARM, REVERSE HOOK - DRIVE SHAFT HOUSING	1,1,1,1		
11		32520	HOOK, REVERSE	2,2,2,2		
12	24	33080	SPRING, TENSION - REVERSE HOOK	2,2,2	SERIAL 00000000-01537069	
12	24	33761	SPRING, TENSION - REVERSE HOOK	2,2	SERIAL 01537070-01684187	
13	10	32527	SCREW, REVERSE HOOKS TO REVERSE HOUSING	1,1,1,1		
14	12	29245	WASHER, REVERSE HOOKS TO REVERSE HOUSING	2,2,2,2		
15	11	20586	NUT, REVERSE HOOKS TO REVERSE HOUSING	1,1,1	SERIAL 00000000-01537143	
15	11	33825	NUT, REVERSE HOOKS TO REVERSE HOUSING	1,1,1	SERIAL 01537144-01684187	
16	10	32694	SCREW, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1,1		
17	12	24675	WASHER, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1	SERIAL 00000000-01537143	
17	12	34016	WASHER, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1	SERIAL 01537144-01684187	
18	24	32659	SPRING, TENSION-REVERSE HOUSING	1,1,1,1		
19		32588A 1	STOP ASSEMBLY, REVERSE HOUSING	1,1,1,1		
20	10	32524	SCREW, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1,1		
21	11	20509	NUT, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1	SERIAL 00000000-01537143	
21	11	33826	NUT, REVERSE HOOK ARM TO REVERSE HOUSING	1,1,1	SERIAL 01537144-01684187	
22		32628	SHAFT, SHIFT - INTERMEDIATE	1,1,1,1		
23	12	32666	WASHER, INTERMEDIATE SHIFT	1,1,1,1		
24	18	32665	COTTER PIN, INTERMEDIATE SHIFT	1,1,1,1		
25	11	22178	NUT, GEAR HOUSING TO DRIVE SHAFT	3,3,3,3		
26		32499A 1	BELL HOUSING ASSEMBLY	1		
26		33506A 1	BELL HOUSING ASSEMBLY	1		
26		33795A 1	BELL HOUSING ASSEMBLY	1		
27	11	32522	NUT, SPLINED - DRIVE SHAFT	6,6		
28	22	32125	CONNECTOR, SHIFT ACTUATOR	1,1,1,1		
29	22	32065	CONNECTOR, WATER HOSE TO SHIFT ACTUATOR	1,1,1,1		