



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	2022A 4	GEAR HOUSING ASSEMBLY, COI	1,1		1
-	1623	2078A 2	GEAR HOUSING ASSEMBLY, COI	1,1		1
-	1623	2078A 3	GEAR HOUSING ASSEMBLY, COI	1,1		1
1	1623	2022A 3	GEAR HOUSING ASSEMBLY	1,1		
1	1623	2078A 1	GEAR HOUSING ASSEMBLY	1,1		
2	16	29080	STUD, GEAR HOUSING TO D	1,1,1,1		
3	16	29078	STUD, GEAR HOUSING TO D	2,2,2,2		
4	16	30669	STUD, WATER PUMP BASE A	1,1,1,1		
5	16	30667	STUD, WATER PUMP BASE A	2,2,2,2		
6	31	29982	BEARING, ROLLER - DRIVE S	1,1		
6	31	32898	BEARING, ROLLER - DRIVE S	1,1		
7	17	21438	PIN, DOWEL - GEAR HOUSIN	2,2		
8	45	32594	DRIVE SHAFT	1,1		
8	45	33133A 1	DRIVE SHAFT ASSEMBLY	1,1		
8	45	34441A 1	DRIVE SHAFT ASSEMBLY	1,1		
9	17	30545	PIN, DRIVE SHAFT	1,1		
10	24	20254	SPRING, COMPRESSION - DF	1,1		
10	24	34576	SPRING, COMPRESSION - DF	1,1		
11	25	30613	"O" RING, UPPER - DRIVE SF	1,1,1,1		
12	43	31419	GEAR, PINION - DRIVE SHAFT	1,1		
12	43	33134	GEAR, PINION - DRIVE SHAFT	1,1		
13	11	30932	NUT, PINION GEAR TO DRIVE	1,1,1,1		
14	15	30278A 1	SHIM, DRIVE SHAFT BEARING	AR,AR		
14	15	33143A 1	SHIM, DRIVE SHAFT BEARING	AR,AR		
15	30	30464	BEARING, BALL - DRIVE SHAFT	1,1		
16	53	30726	RING, RETAINING - BALL BEAR	1,1		
17	15	30278A 1	SHIM, DRIVE SHAFT BEARING	AR,AR		
18	31	33138A 1	TAPERED ROLLER BEARING A	1,1		
18	31	34448A 1	TAPERED ROLLER BEARING A	1,1		
19	31	33139	CUP, TAPERED ROLLER BEA	1,1		
20	11	33672	NUT, ROLLER BEARING TO DF	1,1		
21	27	32438	GASKET, WATER PUMP BASE	1,1		
21	27	33146	GASKET, WATER PUMP BASE	1,1		
22	25	30224	"O" RING, WATER PUMP BASE	1,1		
22	25	33145	"O" RING, WATER PUMP BASE	1,1		
23	46	32436A 1	WATER PUMP BASE ASSEMBL	1,1		
23	45	33132A 1	WATER PUMP BASE ASSEMBL	1,1		
23	46	34447A 1	WATER PUMP BASE ASSEMBL	1,1		
24	26	31489	OIL SEAL, WATER PUMP BAS	1,1		
24	26	33144	OIL SEAL, WATER PUMP BAS	1,1		
25	26	21507	OIL SEAL, WATER PUMP BAS	1,1		