



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		37974	PLATE,TRANSOM	1		
2	54	37282	CLAMP,CUT-OUT SWITCH LEAD:	1	USE WITH BOLT AND NUT DISC	
3	10	28635	SCREW, LEADS CLAMP TO TRAN	1	USE WITH BOLT AND NUT DISC	
4		37281	"D" WASHER, LEADS CLAMP SC	1	USE WITH BOLT AND NUT DISC	
5	38	32738	SERIAL PLATE	1	EARLY STYLE	
6	10	22290	SCREW, DRIVE-SERIAL PLATE T	2	EARLY STYLE	
7		39395	DECAL, SERIAL NUMBER LATE E	1		
8	23	32585	LEAVER, SHIFT CONTROL TRAN	1		
9	16	31758	SPACER, SHIFT CONTROL LEVER	1		
10	12	32698	STUD, SHIFT CONTROL LEVER	1		
11	11	26825	WASHER, SHIFT CONTROL LEVE	2		
12	16	21528	NUT, SHIFT CONTROL LEVER TC	1		
13	12	34069	STUD, SHIFT ACTUATING CABLE	1		
14	12	39143	WASHER, SHIFT ACTUATING CA	3		
15	11	20361	NUT, SHIFT ACTUATING CABLE	2		
16	10	22659	SCREW, SHIRT CABLE ASSEMBL	1		
17	23	31866	SPACER, SHIFT CABLE ASSEMBL	1		
18	12	39143	WASHER, SHIFT CABLE ASSEMBE	2		
19	11	20361	NUT, SHIFT CABLE ASSEMBLY T	1		
20		37979A	ARM ASSEMBLY, SWITCH ACTUA	1		
21	24	32464	PLUNGER, SWITCH ACTUATING	2		
22	24	39426	SPRING, COMPRESSION-SWIT	1		
23	16	33501	RETAINER, SPRING AND PLUN	1		
24	16	32467	STUD, SWITCH ACTUATING ARM	1		
25	23	37981	SPACER, SWITCH ACTUATING A	1		
26	12	26825	WASHER, SWITCH ACTUATING	2		
27	11	35814	NUT, SWITCH ACTUATING ARM	1		
28	10	25299	SCREW, SWITCH ACTUATING AF	1	THE ENCLOSED PARTS ARE US	
29	13	26993	LOCKWASHER, SWITCH ACTUA	1	THE ENCLOSED PARTS ARE US	
30	12	22753	WASHER, SWITCH ACTUATING	1	THE ENCLOSED PARTS ARE US	
31	30	30866A	SWITCH ASSEMBLY, CUT-OUT-T	1	BOLT AND NUT DISCONNECT	
32	10	30902	SCREW, SWITCH ASSEMBLY TO	2	BOLT AND NUT DISCONNECT	
33	10	34695	SCREW, SWITCH ASSEMBLY LE	2	BOLT AND NUT DISCONNECT	
34	11	20645	NUT, SWITCH ASSEMBLY LEAD	2	BOLT AND NUT DISCONNECT	
35	23	32914	SLEEVE, SWITCH ASSEMBLY LE	2	BOLT AND NUT DISCONNECT	
36	10	39671A	SWITCH ASSEMBLY, CUT-OUT-T	1	QUICK-DISCONNECT	
37	10	30902	SCREW, SWITCH ASSEMBLY TO	2	QUICK-DISCONNECT	
38	10	39974	CONNECTOR, CUT-OUT SWITCH	2	QUICK-DISCONNECT	
39	10	37892	SCREW, CONNECTOR TO TRAN	2	QUICK-DISCONNECT	
40	18	32857	COTTER PIN, SHIFT ACTUATING	1		
41	10	32769	SCREW, TRANSOM PLATE TO G	2	THE ENCLOSED PARTS ARE IN	