



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	37991	HOSE, LIFT - HYDRAULIC PUMP	1		
2	54	22627	CLIP, LIFT HOSE TO TRANSOM F	1		
3	10	31903	SCREW, LIFT HOSE TO TRANSO	1		
4	32	36085	HOSE, CONNECTING - GIMBAL F	1		
5	32	36086	HOSE, CONNECTING - GIMBAL F	1		
6		36011	COVER, CONNECTING HOSE TO	2		
7	10	36070	SCREW, COVER TO GIMBAL HOL	4		
8	22	36033	CONNECTOR, GIMBAL HOUSING	1		
9	27	36043	GASKET, GIMBAL HOUSING CON	1		
10	11	36084	NUT, GIMBAL HOUSING CONNEC	1		

