



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32420A 2	STEERING LEVER HOUSING ASSE	1	15 1/2" "U" JOINT COUPLING YI	
1		52756A 2	STEERING LEVER HOUSING ASSE	1	11 1/2" "U" JOINT COUPLING YI	
1	31	30457	BEARING, ROLLER - STEERING	2		
2	26	31851	OIL SEAL, STEERING LEVER H	2		
4	22	23612	FITTING, GREASE - STEERING	1		
5		29359	LUBRICAPM, STEERING LEVEF	1		
6	32	31879	TUBE, NYLON - SHIFT ACTUAT	1		
7	27	32423	GASKET, STEERING LEVER HOL	1		
8	16	32422	STUD, STEERING LEVER HOUSI	1		
9	16	32421	STUD, STEERING LEVER HOUSI	1		
10	12	20959	WASHER, STEERING LEVER HO	2		
11	11	28040	NUT, STEERING LEVER HOUSI	2		
12	22	25885	ELBOW, STEERING LEVER HOU	1		
13	37	39395	DECAL, SERIAL NUMBER	1		
14	54	24836	CLIP, TILT STOP SWITCH LEA	1		
15	10	26548	SCREW, TILT STOP SWITCH LE	1		
16		22789	"D" WASHER, TILT STOP SWITC	1		
17		34903	ARM, STEERING - LOWER	1		
18	10	31846	BOLT, LINK ROD TO LOWER STE	1		
19	23	31853	BUSHING, LINK ROD BOLT	1		
20	11	31847	NUT, LINK ROD BOLT	1		
21	10	31830	SCREW, LOWER STEERING AR	1		
22	14	31828	TAB WASHER, LOWER STEERIN	1		
23		34009	LINK ROD, LOWER STEERING R	1		
24	10	34954	BOLT, LINK ROD TO GIMBAL RIN	1		
25	23	31853	BUSHING, LINK ROD BOLT	1		
26	11	31844	NUT, LINK ROD BOLT	1		
27		31844	SHAFT, STEERING - LEVER HOU	1		
28	12	31829	WASHER, NYLON - UPPER AND	2		
29		33775	ARM, STEERING - UPPER (15 1/2	1		
29		52744	ARM, STEERING - UPPER (11 1/2	1		
29		53355	ARM, STEERING - UPPER (TRAN	1		
30	12	35685	WASHER, UPPER STEERING AR	1		
31		35096	YOKE, UPPER STEERING ARM	1	SERIAL 00000000-02558100	
32	10	35095	SCREW, STEERING CABLE TO Y	1	SERIAL 00000000-02558100	
33	12	20084	WASHER, STEERING CABLE SCF	1	SERIAL 00000000-02558100	
34	11	20102	NUT, STEERING CABLE SCREW	1	SERIAL 00000000-02558100	
31		53213A 1	YOKE ASSEMBLY, UPPER STEEF	1	SERIAL 02558101-09999999	
32	10	24644	SCREW, STEERING CABLE TO	1	SERIAL 02558101-09999999	
33	23	47643	BUSHING, STEERING CABLE S	1	SERIAL 02558101-09999999	
34	11	20261	NUT, STEERING CABLE SCREW	1	SERIAL 02558101-09999999	