



DRIVE SHAFT HOUSING ASSEMBLY AND SHIFT CABLE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1544	3442A 1	DRIVE SHAFT HOUSING ASSEMBLY	1		
2	23	38335	BUSHING, SYNTHANE - DRIVE	2		
3	37	39428A 1	DECAL SET, DRIVE SHAFT HOUSING	1		
4	16	32129	STUD, DRIVE SHAFT HOUSING	8		
5	22	31345	FITTING, GREASE - DRIVE SHAFT HOUSING	2		
6		29359	LUBRICAP, DRIVE SHAFT HOUSING	2		
7		34057A 1	EYE ASSEMBLY, SHIFT ACTUATING CABLE	1		
8	23	34058	SPACER, SHIFT ACTUATING CABLE	1		
9	11	34059	NUT, SHIFT ACTUATING CABLE	1		
10	10	28668	SCREW, DRIVE SHAFT HOUSING	3		
11		49286	FORK, SHIFT - SLIDING CLUTCH	1		
12		35181A 1	SHIFT LINK ASSEMBLY, DRIVE SHAFT HOUSING	1		
13	10	31856	SCREW, SHIFT LINK TO SHIFT FORK	1		
14	11	20664	NUT, SHIFT LINK SCREW	1		
15		35180	YOKE, SHIFT LINKER TO YOKER	1		
16	10	36285	SCREW, SHIFT LINK TO YOKER	3		
17	11	20061	NUT, SHIFT LINK SCREW	1		
18	43	35178	GEAR, SECTOR - GEAR RACK GL	1		
19		31722	SHAFT, SPLINED - SECTOR GEAR PIVOT	1		
20	18	20180	COTTER PIN, SECTOR GEAR PIVOT	1		
21	12	30283	WASHER, SECTOR GEAR PIVOT	1		
22	43	31719	GEAR, REVERSE LOCK - SECTOR GEAR RACK	1		
23		31655	GUIDE, GEAR RACK - DRIVE SHAFT HOUSING	1		
24	10	28668	SCREW, GEAR RACK TO DRIVE SHAFT HOUSING	4		
25	14	31651	TAB WASHER, GEAR RACK GUIDE	4		
26	10	31700	SCREW, SET-SHIFT ACTUATING CABLE	1		
27		31573	RACK, GEAR-SHIFT ACTUATING CABLE	1		
28	22	32125	CONNECTOR, SHIFT ACTUATING CABLE	1		
29		52922	WRAPPING, SHIFT ACTUATING CABLE	1	11 1/2" "U" JOINT COUPLING Y	
30		31720A 1	CABLE ASSEMBLY, SHIFT ACTUATING CABLE	1		
30		53764A 1	CABLE ASSEMBLY, SHIFT ACTUATING CABLE	1		
--	12	39279	WASHER, LEATHER-SHIFT ACTUATING CABLE	1		
31		33075A 2	CORE WIRE AND ANCHOR ASSEMBLY	1		
32		29880	GUIDE, SHIFT ACTUATING CABLE	1		
33		20007	ANCHOR, SHIFT ACTUATING CABLE	1		
34	10	20518	SCREW, SET-ANCHOR TO SHIFT FORK	2		