



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1544	1976A 3	DRIVE SHAFT HOUSING ASSEMBLY	1	A12 FOR PARTS BREAKDOWN	
1	1544	1981A 3	DRIVE SHAFT HOUSING ASSEMBLY	1	A12 FOR PARTS BREAKDOWN	
1	1544	2008A 8	DRIVE SHAFT HOUSING ASSEMBLY	1	A12 FOR PARTS BREAKDOWN	
2	19	29850	PLUG, TRIM TAB HOLE - DRIVE	1,1,1,1		
3	27	31662	GASKET, DRIVE SHAFT HOUSING	1		
3	27	32858	GASKET, DRIVE SHAFT HOUSING	1		
3	27	32277	GASKET, DRIVE SHAFT HOUSING	1,1		
4		31596A 1	COVER ASSEMBLY, SHIFT FORK	1,1		
4		32365A 1	COVER ASSEMBLY, SHIFT FORK	1,1		
5		26183A 1	EMBLEM, SHIFT FORK COVER	1,1,1,1		
6	22	32018	PLUG, OIL FILLER - SHIFT FORK	1,1,1,1		
7	27	32019	GASKET, OIL FILTER PLUG - SHIFT FORK	1,1,1,1		
8	27	31637	GASKET, SHIFT FORK COVER TO CLUTCH	1,1		
8	27	32366	GASKET, SHIFT FORK COVER TO CLUTCH	1,1		
9	10	31716	SCREW, SHIFT FORK COVER TO CLUTCH	6,6,6,6		
10	25	32068	"O" RING TOP COVER SEALING	1,1,1,1		
11	15	32058A 1	SHIM, TOP COVER TO DRIVE SHAFT HOUSING	AR,AR		
11	15	32363A 1	SHIM, TOP COVER TO DRIVE SHAFT HOUSING	AR,AR		
12		32056	COVER, TOP - DRIVE SHAFT HOUSING	1,1		
12		32367	COVER, TOP - DRIVE SHAFT HOUSING	1,1	(PART OF B-1544-2008A8 DRIVE	
13	10	31985	SCREW, TOP COVER TO DRIVE SHAFT HOUSING	5,5,5,5		
14	52	31530	CLUTCH, SLIDING - SHIFT FORK	1,1,1,1		
15	43	32261	GEAR, FORWARD	1,1,1,1		
16	15	32061A 1	SHIM, ROLLER BEARING WASHER	AR,AR	(.002-3-5-10-25)	
17	12	32161	WASHER, FORWARD GEAR TAB	1,1,1,1		
18	31	30894A 4	TAPERED ROLLER BEARING ASSEMBLY	1,1,1,1		
19	14	32054	TAB WASHER, TAPERED ROLLER BEARING	1,1,1,1		
20	11	32060	NUT, TAPERED ROLLER BEARING	1,1,1,1		
21	43	32262	GEAR, REVERSE	1,1,1,1		
22		32087	RETAINER, REVERSE GEAR TAB	1,1,1,1		
--		32108	BALL, TAPERED ROLLER BEARING	1		
--	10	32106	SCREW, SET - TAPERED ROLLER BEARING	1		
23	10	32130	SCREW, SET - TAPERED ROLLER BEARING	2,2,2		
24	11	26484	NUT, JAM TAPERED ROLLER BEARING	2,2,2		
25	31	30894A 4	TAPERED ROLLER BEARING ASSEMBLY	1,1,1,1		
26	15	32057A 1	SHIM, REVERSE GEAR BEARING CLUTCH	AR,AR	(.002-3-5-10-25)	
27	14	32054	TAB WASHER, TAPERED ROLLER BEARING	1,1,1,1		
28	11	32060	NUT, TAPERED ROLLER BEARING	1,1,1,1		
29		32051	UNIVERSAL JOINT, PINION GEAR	1,1,1,1		
30		36312	CROSS AND BEARING ASSEMBLY	2,2,2,2		
31		31576	RETAINER, PINION GEAR ROLLER	1,1,1,1		