



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		34193	PALTE, TRANSOM - INNER	1,1,1,1	
2		32616	CATCH, CLAMP NUT (PART OF B	1,1,1,	
2A		33639	CATH, CLAMP NUT (PART OF B:	...1	
3	10	21365	SCREW, CATCH TO CLAMP NUT	2,2,2,	
3	10	32759	SCREW, CATCH TO CLAMP NUT	...3	
4	13	21547	LOCKWASHER, CATCH TO CLAM	2,2,2,	
4	13	21547	LOCKWASHER, CATCH TO CLAM	...3	
-		32300A 1	COVER ASSEMBLY, CLAMP NUT	1,1,1,1	
5		32300	COVER, CLAMP NUT - INNER T	1,1,1,1	
6		32761	NUT, CLAMP - STEERING LEVEF	1,1,1,1	
7	110	25503	SCREW, CLAMP NUT COVER TO	1,1,1,1	
8	10	31984	SCREW, CLAMP NUT COVER TO	5,5,5,5	
9	12	20103	WASHER, CLAMP NUT COVER T	6,6,6,6	
10	10	31983	SCREW, STEERING LEVEL HOU	1,1,1,1	
11	54	24836	CLIP, TILT STOP SWITCH LEA	1,1,1,1	
12	10	32031	SCREW, TILT STOP SWITCH LEA	1,1,1,1	(10-32 SELF TAPPING THREAD)
12	10	25764	SCREW, TILT STOP SWITCH LEA	...1	(10-32 STANDARD THREAD)
13		22789	"D" WASHER, TILT STOP SWITC	1,1,1,1	
14		32169	TERMINAL BLOCK, INNER TRAN	1,1,,	
14		30212	TERMINAL BLOCK, INNER TRAN	..1,1	
15	10	28739	SCREW, TILT STOP SWITCH TO	4,4,,	
15	10	30663	SCREW, TILT STOP SWITCH TO	..2,2	
16	10	32024	SCREW, TERMINAL BLOCK TO IP	2,2,2,2	
17	12	31855	WASHER, THRUST - WORM GEA	1,1,,	
18	43	31605	GEAR, WORM - INNER TRANSOM	1,1,1,1	
19	17	31728	PIN, WORM GEAR - SLEEVE ANC	2,2,2,2	
20	23	31857	BUSHING, NYLON - WORM GEA	1,1,1,1	
21	12	31727	WASHER, THRUST - WORM GEA	1,1,1,1	
22		31631	COVER, RETAINING - WORM GE	1,1,1,1	
23	24	31729	SPRING, COMPRESSION - WORM	1,1,1,1	
24	23	31726	SLEEVE, WORM GEAR LOCKING	1,1,1,1	
25		31730	LOCK, SPLINED - WORM GEAR L	1,1,1,1	
26	10	21324	SCREW, WORM GEAR COVER AI	2,2,2,2	
27	13	26992	LOCKWASHER, WORM GEAR CC	2,2,2,2	
28		33923A10	CRANK ASSEMBLY (10")	OPT..0	
28		33923A16	CRANK ASSEMBLY (16")	OPT..0	
28		33923A22	CRANK ASSEMBLY (22")	1,1,1,1	
28		33923A28	CRANK ASSEMBLY	OPT..0	
28		33923A34	CRANK ASSEMBLY (34")	OPT..0	
29	37	32187	LABEL, DIRECTIONAL AND INS	1,1,1,1	
30		21842	KNOP, CRANK	1,1,1,1	