



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47342A 1	TRIM CYLINDER ASSEMBLY, COI	2		
1		47342A 3	TRIM CYLINDER ASSEMBLY, COI	2		
2	17	47375	PIN, ANCHOR - DRIVE SHAFT HC	1		
3	12	47395	WASHER, DRIVE DSHAFT HOUS	2		
4	24	49593	SPRING, DRIVE SHAFT HOUSINC	2		
5	23	47392	BUSHING, RUBBER - DRIVE SHA	4		
6	12	47394	WASHER, DRIVE SHAFT HOUSIN	2		
7	11	35000	NUT, DRIVE SHAFT HOUSING AP	2		
8	17	47374	PIN, ANCHOR - TRIM CYLINDER	1		
9	12	47395	WASHER, GIMBAL RING ANCHOR	2		
10	24	49593	SPRING, GIMBAL RING ANCHOR	2		
11	23	47392	BUSHING, RUBBER - GIMBAL RIN	4		
12	12	47394	WASHER, GIMBAL RING ANCHOR	2		
13	11	35000	NUT, GIMBAL RING ANCHOR PIN	2		
14	32	47373	HOSE, HYDRAULIC - CONNECTO	4		
15	32	47382	HOSE, HYDRAULIC - CONNECTO	1		
16	32	47399	HOSE, HYDRAULIC - CONNECTO	1		
17	54	22740	CLIP, HYDRAULIC HOSE TO TRA	3		
17	54	39844A 1	CLIP ASSEMBLY, HYDRAULIC HC	1		
18	10	30663	SCREW, HYDRAULIC HOSE CLIP	4		
19		22789	"D" WASHER, HYDRAULIC HOSE	4		
20	32	48327A 2	TUBE ASSY, PUMP TO REVERSE	1		