



2214

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		863077T	ALTERNATOR ASSEMBLY, (Black)	1	(Non Serviceable)	
2	11	40021	NUT, (M6)	2		
3	10	400011 34	SCREW, (M8 X 25)	1		
4	10	828213	SCREW, (.312-18 x 1.500)	2		
5	12	57792	WASHER	2		
6	11	859119	NUT, (.312-18)	2		
7		863211T01	BRACKET, Alternator Mounting	1		
8	10	98261	SCREW, (.375-16 x .750)	2		
9	12	20084	WASHER, (.328 x .562 x .062)	1		
10		865188T01	BRACKET	1	(With-out Air Actuated Drain)	
10		865188T	BRACKET	1	(With Air Actuated Drain)	
11		862083T	BRACKET, Idler Adjustment	1		
12		818380T	BUSHING	1		
13	11	859135	NUT, (.437-20)	1		
14	43	818381	PINION STUD	2		
15		864625T	PULLEY (4.25 Inch Diameter)	1	(With Power Steering)	
15		807757T	PULLEY (3.00 Inch Diameter)	1	(Compact Hydraulic Steering)	
16	10	34353	SCREW, (.375-16 x 1.00)	2		
17		862082T	BRACE, Power Steering	1		
18	10	40001188	SCREW, (M10 x 20)	1		
19		864456T	BRACKET, Alternator Brace	1	(Bravo) (Alpha-Closed Cooling)	
20	10	34353	SCREW, (.375-16 x 1.00)	1		
21		862085T	BRACE, Idler Bracket	1	(Bravo) (Alpha-Closed Cooling)	
22		818382	PULLEY	1	(Bravo) (Alpha-Closed Cooling)	
23		818380T	BUSHING	1	(Bravo) (Alpha-Closed Cooling)	
24	10	56393	SCREW, (.437-20 x 1.75)	1	(Bravo) (Alpha-Closed Cooling)	
25	11	859135	NUT, (.437-20)	1	(Bravo) (Alpha-Closed Cooling)	
26		862778	BRACKET, Alternator Brace	1		
27	10	34353	SCREW, (.375-16 x 1.00)	1		
28	57	863876 4	BELT, Serpentine	1	(Standard Cooling) (Alpha) (With P	
28	57	863876 9	BELT, Serpentine	1	(Standard Cooling) (Alpha) (CHS ai	
28	57	863876 3	BELT, Serpentine	1	(Standard Cooling) (Bravo) (With P	
28	57	863876 8	BELT, Serpentine	1	(Standard Cooling) (Bravo) (CHS a	
28	57	863876 6	BELT, Serpentine	1	(Alpha/Bravo) (Closed Cooling) (W	
28	57	863876 8	BELT, Serpentine	1	(Alpha/Bravo) (Closed Cooling) (Cf	