



9807

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	23	818465	BEARING SET, (5 Pair)	1	(Standard) (5.0L/350)	
1	23	818466	BEARING SET, (5 Pair)	AR	(.001 Undersized) (5.0L/350)	
1	23	818467	BEARING SET, (5 Pair)	AR	(.010 Undersize) (5.0L/350)	
1	23	818468	BEARING SET, (5 Pair)	AR	(.020 Undersized) (5.0L/350)	
1	23	849396	BEARING SET, (5 Pair)	1	(Standard) (6.2L)	
1	23	849395	BEARING SET, (5 Pair)	AR	(.001 Oversized) (6.2L)	
1	23	849394	BEARING SET, (5 Pair)	AR	(.001 Undersize) (6.2L)	
2	17	43504	PIN, Dowel (.250)	2		
3	429	9521 1	CRANKSHAFT	1	(5.0/350)	
3	429	863323T 1	CRANKSHAFT	1	(6.2L)	
4	28	34466	KEY, Crankshaft	2	(5.0L/350)	
4	28	862594	KEY, Crankshaft	1	(MX-6.2L)	
5		NSS	NOT SOLD SEPARATE, Cap, Crar	0		
6	10	862567 1	SCREW, Crankshaft Bearing Cap	10		
7	16	850090	STUD, (.437-14/.375-16 x 3.360). (5		
8	23	85674	BEARING SET	1		
9		17341	GUIDE, Lifter	8		
10		17340T 1	LIFTER, Roller	16		
11	431	811658	CAMSHAFT	11	(5.0L)	
11	431	866022T	CAMSHAFT	1	(350 Mag)	
11	431	862562T 1	CAMSHAFT	1	(6.2L)	
12	17	843378	PIN, Dowel	1		
13		811662	RETAINER, Lifter Guide	1		
14	10	34500	SCREW, (.312-18 x .625)	3		
15	22	864669	FITTING	1		
16		881879A 2	SENSOR KIT, (100 PSI), Oil Press	1		
17	87	815425T	SENDER ASSEMBLY, Oil Pressure	1		
17		37293T	SENDER ASSEMBLY, Oil Pressure	OPT	(Dual Station)	
18	13	26996	LOCKWASHER, (#10)	1		
19	11	68219	NUT, (#10-32)	1		
-		863660A 2	LONGBLOCK	1	(5.0L MPI)	
-		866138A03	LONGBLOCK	1	(350 Mag)	
-		865108A02	LONGBLOCK	1	(MX 6.2L-MPI)	
-	92	809825	RTV SILICONE, Metallic Blue	1	(Where Applicable)	
-	92	34227 1	SEALING COMPOUND, (16 Ounce)	1	(Where Applicable)	