



19362

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	805059	FITTING	1		
2	87	815425T	SENDER ASSEMBLY	1		
3		37293T	SENDER ASSEMBLY (DUAL STA	OPT		
3		97257A 1	SENDER ASSEMBLY, Water Tem	1		
3		49734	SENDER (DUAL STATION)	OPT		
4	13	26996	LOCKWASHER, (#10)	2		
5	11	68219	NUT, (#10-32)	2		
6	22	32974	FITTING, (.125-.27) Adaptor	1		
7	87	805605A 1	SWITCH ASSEMBLY	1		
8		816492A 6	ALARM KIT	1		
9		805592A 1	CONNECTOR ASSEMBLY	1		
10		806612T	SENSOR, Knock	1		
11		805218T	SENSOR	1		
12	22	806705 1	FITTING, Dual	1		
13	84	861940T 1	HARNESS	1		
14	84	862021T 1	HARNESS	1		