



14694

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	23	818465	BEARING SET, (5 Pair)	1	(Standard) (350)	4
1	23	818466	BEARING SET, (5 Pair)	AR	(.001 Undersize) (350)	4
1	23	818467	BEARING SET, (5 Pair)	AR	(.010 Undersize) (350)	4
1	23	818468	BEARING SET, (5 Pair)	AR	(.020 Undersize) (350)	4
1	23	849396	BEARING SET, (5 Pair)	1	(6.2L) (Standard)	4
1	23	849395	BEARING SET, (5 Pair)	AR	(6.2L) (.001 Oversize)	4
1	23	849394	BEARING SET, (5 Pair)	AR	(6.2L) (.001 Undersize)	4
2	17	43504	PIN, Dowel (.250)	2		4
3	429	9521	1 CRANKSHAFT	1	(350)	4
3	429	863323T1	CRANKSHAFT	1	(6.2L)	4
4	28	34466	KEY, Crankshaft	2	(350 Magnum)	4
4	28	862594	KEY, Crankshaft	1	(MX6.2L)	
5		NSS	NOT SOLD SEPARATE, Cap, Crar	0		4
6	10	862567	1 SCREW, Crankshaft Bearing Cap	5		1,4
7	16	850090	STUD, (.437-14/.375-16 x 3.360), (5		4
8	23	85674	BEARING SET	1		4
9		17341	GUIDE, Lifter	8		4
10		17340T	1 LIFTER, Roller	16		4
11	431	811658	CAMSHAFT	1	(350)	4
11	431	862562T	1 CAMSHAFT	1	(6.2L)	4
12	17	35312	PIN, Dowel	1		4
13		811662	RETAINER, Lifter Guide	1		4
14	10	34500	SCREW, (.312-18 x .625)	3		4
15	22	863658	FITTING	1		1
16		881879A	6 SENSOR, (0 - 100 PSI), Oil Pressur	1		
17	87	815425T	SENDER ASSEMBLY, Oil Pressure	1		
17		37293T	SENDER ASSEMBLY, Oil Pressure	OPT	(Dual Station)	
18	13	26996	LOCKWASHER, (#10)	1		
19	11	68219	NUT, (#10-32)	1		
-	92	809825	RTV SILICONE, Metallic Blue, Whe	1		
-	92	34227	1 SEALING COMPOUND, (16 Ounce)	1		