



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	32	863489	HOSE, Transmission Cooler To Che	1	
2	21	864206A	CHECK VALVE ASSEMBLY	1	
3	32	864480	HOSE, Check Valve To Tee Fitting	1	
4	32	864481	HOSE, T Fitting To Fuel Cooler	1	
5	32	863670	HOSE, Fuel Cooler To Water Distrib	1	1
6	32	863490	HOSE, Water Drain Accumulator T	1	1
7	22	864450	FITTING, Lower Distribution	1	1
8	32	863491	HOSE, Distribution Fitting To "Y" Fi	1	1
9	32	862274	HOSE, Lower Circulation Pump	1	1
10	32	863453	HOSE, Y Fitting To Circulating Pum	1	1
11	32	863465	HOSE, Drain Accumulator To Tee f	1	1
12	32	863496	HOSE, T Fitting To Port Elbow	1	1
13	32	863828	HOSE, T Fitting To Starboard Elbow	1	
14	32	863459	HOSE, Thermostat Housing To Star	1	
15	32	864393	HOSE, Thermostat Housing To Port	1	1
16	32	864477	HOSE, Sea Water Pump To "T" Fit	1	1
17	32	864478	HOSE, T Fitting To Trans Cooler	1	
18	22	862225	FITTING, Pushlock	4	1
19	32	862317	HOSE, Cylinder Block Drain To Dist	2	(Port-23.00 Inch) (Starboard-17 Inc
20	32	42850	HOSE, (44.00 Inches Bulk)	1	(Cut To Fit.)
21	25	62702	O-RING, (.301 x .070)	2	
22	22	863464A	FITTING	1	1
NS	23	864327	BUSHING, Oriface	1	1
NS	25	864353	O-RING	1	1
23	22	862993	FITTING	3	
24	54	815504212	CLAMP, Worm Gear, Hose	2	
25	54	815504216	CLAMP, Worm Gear, Hose	AR	
26	54	815504222	CLAMP, Worm Gear, Hose	2	
27	54	815504228	CLAMP, Worm Gear, Hose	1	
28	54	815504232	CLAMP, Worm Gear, Hose	AR	
29	22	862603	FITTING, Male Quick Connector (T	2	
30		863455	FITTING, Y	1	1
31	32	863343	HOSE, Sea Water Pump To Water	1	
32	22	861427	CAP	1	
33	22	861405	FITTING	1	
34	22	861406	SOCKET	1	
NS	19	807992	COVER, Hose Clamp End	AR	