



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	<a href="#">8951A43</a>	GEAR HOUSING ASSEMBLY, CO	1		
1	1623	8951A37	GEAR HOUSING ASSEMBLY BL	1		
53		76865	SHIFT CRANK	1		
<b>54</b>	18	46950	1 COTTER PIN	1		5
55		NSS	ADJUSTING SLEEVE	1	(Replacement Spool Assembly 81E	
56		NSS	RETAINER	1	(Replacement Spool Assembly 81E	
57		NSS	WASHER	2	(Replacement Spool Assembly 81E	
58		NSS	SPRINGER	1	(Replacement Spool Assembly 81E	
59		NSS	SPOOL	1	(Replacement Spool Assembly 81E	
60		NSS	SHAFT	1	(Replacement Spool Assembly 81E	
<b>61</b>	15	47397A	1 SHIM	AR		7,8,9
<b>62</b>	31	35928T	1 TAPERED ROLLER BEARING A	AR		5,7,8,9
<b>63</b>		NSS	FORWARD GEAR	1		7
<b>64</b>	31	42679	ROLLER BEARING (TORRING	AR		8,9
<b>64</b>	31	30895T	ROLLER BEARING (TORRING	AR		5,7,8,9
<b>65</b>	52	853594T	CLUTCH	1		9
66	17	30632	CROSS PIN	1		
67	24	30893	SPRING	1		
68	44	824110	PROPELLER SHAFT	1		
<b>69</b>	43	824109A	1 REVERSE GEAR	1		7,9
70		68100	1 THRUST RING	1		
<b>71</b>	30	88957T	BALL BEARING	1		7,8,9
<b>72</b>	25	31534	O-RING	1		3,8,9
73		73020A14	CARRIER ASSY (CASTING #73	1		
73		818763A10	CARRIER ASSY. (CASTING #73	1		
<b>74</b>	31	30956T	ROLLER BEARING	1		7,8,9
<b>75</b>	26	76868	OIL SEAL	2		3,8,9
<b>75</b>	26	14077	OIL SEAL (INSIDE) CUTTER SE	1		
<b>75</b>	26	12224	OIL SEAL (OUTSIDE) CUTTEF	1		3,8,9
76	28	30281	KEY	1		
<b>77</b>	14	79447	TAB WASHSER (USE WITH 7302	1		8,9
<b>77</b>	14	18323	TAB WASHER (USE WITH 7302	1		8,9
78		79448	COVER	1		
79	12	835467	1 THRUST HUB (FOR USE W/"BLA	1		
79		56292A	4 THRUST HUB (FOR USE W/M/C	1		
80	12	31211A	3 WASHER, SPLINED	1		
81	14	816629	TAB WASHER	1		
82	11	<a href="#">52707Q</a>	1 NUT	1		
83		<a href="#">31640Q</a>	4 TRIM TAB ASSEMBLY (2-3/8")	1		
83		34127T	2 TRIM TAB ASSEMBLY (4")	OPT	THIS TRIM TAB CANNOT BE US	
84	10	22470	SCREWS (1.24")	1		