



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
--		14336A17	HYDRAULIC PUMP ASSEMBLY	1		
1	392	9252	VALVE BODY AND GEAR ASSE	1		
2	10	69570	SCREW, VALVE BODY TO RESI	8		
3	392	7735	SEAL, RESERVOIR TO VALVE	1		
4	392	7731	RESERVOIR ASSEMBLY (PLAS	1		
5	392	7732	WASHER, THRUST - ARMATUF	1		
6	392	9248	ARMATURE, FIELD AND FRAMI	1		
7	392	9249	FIELD AND FRAME ASSEMBLY	1		
8	392	9250	PLATE ASSEMBLY, COMMUTA	1		
9	392	8989	BRUSH SET, COMMUTATOR	1		
10	392	8993	SPRING SET, GBRUSH TENSIC	1		
11	392	9251	BOLT SET, THRU	1		
12	392	7728	FILL PLUG, RESERVOIR	1		