



18782

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3509	812421A 2	DRIVESHAFT HOUSING ASSEMB	1		
2	22	56800	PLUG, Pipe (.0625-27)	1		
3	16	57985	STUD (2.810)	6		
4	26	38105	OIL SEAL	1		1
5	37	14489A87	DECAL SET	1		1
6	16	13208	STUD	4		
7	10	14834	SCREW, (.735-16), Vent (.375-16) (1		
8	12	19183	WASHER, Fiber	1		
9	43	813803A 3	GEAR SET (Pinion and Drive)	1	(1.00:1 RATIO)	
9	43	813804A 3	GEAR SET (Pinion and Drive)	1	(1.18:1 RATIO)	
9	43	87825A 2	GEAR SET (Pinion and Drive)	1	(1.25:1 RATIO)	
9	43	64973A 3	GEAR SET (Pinion and Drive)	1	(1.33:1 RATIO)	
9	43	92849A 2	GEAR SET (Pinion and Drive)	1	(1.40:1 RATIO)	
9	43	12407A 1	GEAR SET (Pinion and Drive)	1	(1.50:1 RATIO)	
10	15	34800A 1	SHIM ASS'Y	AR		
11	31	34804A 4	TAPERED ROLLER BEARING AS:	1		
12	23	47285	SPACER	1		
13	12	47451	WASHER	1		
14	11	47449	NUT (Special)	1		1
15		47303 1	ADAPTOR	1		
16	12	47289	WASHER	1		
17		47304	RETAINER	1		
18	11	47302	NUT, (.562-18)	1		
19	24	48442	SPRING	1		
20	20	48219	CHECK VALVE	1		
21	25	48452	QUAD RING	1		
22	27	66925 1	GASKET	1		1
23		12701A 1	VALVE GUIDE ASSEMBLY	1		
24	26	66301	OIL SEAL	1		1
25	25	33145	O-RING, (1.984 x .139)	1		1
26	10	56786	SCREW, (#8-32 X .75)	3		
27		44253A 1	UNIVERSAL JOINT ASSEMBLY	1		
28		44271	YOKE (Driven End)	1		
29		48153	CROSS AND BEARING ASSEMB	2		1
30		63575	SOCKET	1		
31		44253	YOKE (Driving End)	1		
32	15	36178A 1	SHIM SET	AR		
33	31	39908A 1	TAPERED ROLLER BEARING AS:	1		
34	23	47305	SPACER	1		
35	31	34804A 3	TAPERED ROLLER BEARING AS:	1		
36	15	34822A 1	SHIM SET	AR		