



18761

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3500	9552A	DRIVESHAFT HOUSING ASSEMB	1		
2		42724A	COVER ASSEMBLY	1		
3	26	36557	SEAL, Water Inlet Tube	1		1
4	27	55810	GASKET	2		1
5	32	75914	TUBE, Water	1		
6	10	28668	SCREW, (.250-20 x .875)	4		
7		12774	PLATE, Water Restrictor	1		
8	37	13682A90	DECAL SET	1		
9	37	13722A10	DECAL SET	1	(454 MAGNUM) (ALPHA ONE)	
9	37	16416A87	DECAL	1	(320) (ALPHA ONE)	
10	26	96503	OIL SEAL	1		1
11	26	32511	OIL SEAL	1		1
12	15	36178A	SHIM SET	AR		
13	45	55796	DRIVESHAFT	1		
14	25	55801	O-RING	1		
15		94998A	COVER ASSEMBLY, Top	1		
16	31	61100A	BEARING ASSEMBLY, Roller	1		
17	15	45691A	SHIM	AR		
18	25	32546	O-RING	1		1
19	10	98794	SCREW, (.375-16 x 1.00)	4		
20		14860	WEAR PAD (PORT)	1		
20		14861	WEAR PAD (STARBOARD)	1		
21	10	14862	SCREW, (.250-20 x .625)	4		
-	26	32511A	REBUILD KIT	1		