



5127

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		846859A 4	HYDRAULIC PUMP	1	(COMPLETE) (OILDYNE)	
1		818161A 4	HYDRAULIC PUMP ASSEMBLY	1	(See Hydraulic Pump Assembly for	
2		818567	BRACKET, Relay Mount	1		
3	10	38837	SCREW, (.312-18 x 1.12)	1		
4	12	57792	WASHER	2		
5	23	34948	SPACER	1		
6	84	65999A12	GROUND CABLE	1		
7	84	79138A 9	CABLE ASSEMBLY, Black (NEG)	1		
8	10	92051	SCREW, (10-16 x .75)	2		
9	84	79147A 5	HARNESS ASSEMBLY	1		
10	88	79091	FUSE, (20 Ampere)	1		
11		88075	RETAINER, Harness Connector	1		
12	89	68258A 4	STARTER SOLENOID	2		
13	10	41508	SCREW, (.250-20 x .500)	4		
14	11	20110	NUT, (#10-32)	4		
15	11	26484	NUT, (.312-18)	4		
16	88	79023A10	FUSE ASSEMBLY, (110 Ampere)	1		
17	12	96457	WASHER	1		
18	11	21825	NUT, (.250-28)	1		
19	84	65999A11	CABLE	1		
20	84	79139A12	CABLE ASSEMBLY, Red (POSIT	1		
21		46265	BOOT	4		
22	12	22753	WASHER	4		
23	84	79139A26	CABLE, Red	1		
24		87760	PLATE, Mounting	1		
25	10	39349	SCREW, (.312-18 x .750)	1		
26	13	26993	LOCKWASHER, (.312)	1		
27	10	90271	SCREW, (.375-16 x .62)	2		
28	13	58643	LOCKWASHER, (.375)	2		
29	12	45175	WASHER, (.406 x .750 x .104)	4		
30		87762	BRACKET	1		
31	10	63826	SCREW, (.375-16 x 2.50)	2		
32	11	68411	NUT, (.375-16)	2		
33	22	818200	FITTING	1		
34	22	77366	FITTING	2		
35	84	65017A14	HARNESS, Tilt	1		