



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		831104450	HEAD ASSEMBLY-CYLINDER	1		
2	19	833950103	PLUG-EXPANSION	1		
3	19	833930105	PLUG-EXPANSION	6		
4	19	833922107	PLUG-EXPANSION	6		
5		831351320	SEAT-VALVE EXHAUST	6		
6		831311270	SEAT-VALVE INTAKE	6		
7	19	833914101	PLUG-EXPANSION	6		
8		830005080	BALL-STEEL	6		
9	23	831221140	BUSHING-VALVE GUIDE INTAK	12		
10		831108750	STUD	12		
11	19	833924103	PLUG-EXPANSION	6		
12	19	833926102	PLUG-EXPANSION	6		