



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		830401300	ALTERNATOR ASSEMBLY	1		
1		833911030	NUT-Pulley	1		
2		834311360	PULLEY	1		
3		834121140	COLLAR	1		
4		834411150	FAN	1		
5		833101470	FRAME ASSEMBLY-Drive End	1		
6		833111410	FRAME-Drive End	1		
7		833151180	FELT	2		
8		833151190	FELT	1		
9	30	838120122	BEARING	1		
10		833121510	PLATE-Retainer	1		
11		833621090	BOLT	3		
12		833151210	FELT	1		
13		833301600	ROTOR ASSEMBLY	1		
14		834121150	COLLAR	1		
15		833331030	RING-Spacer	1		
16		833501880	HOUSING ASSEMBLY	1		
17		833511060	BUSHING	1		
18		834101710	STATOR	1		
19		833561240	RECTIFIER	1		
20		833531370	HOLDER	1		
21		833871100	INSULATOR	2		
22		833871090	INSULATOR	2		
23		833871080	INSULATOR	1		
24		833871140	INSULATOR	1		
25		830105040	NUT-Terminal	4		
26		833871190	INSULATOR	2		
27		833541020	CONDENSER	1		
28		838005120	BOLT	1		
29	11	831006040	NUT	1		
30		833171480	BOLT	2		
31		833171490	BOLT	1		
32		830063023	BEARING	1		
33		838304082	BOLT	4		
34		833881150	COVER	1		
35		833871200	INSULATOR	1		
36		834451170	CLAMP	1		
37		833871120	INSULATOR	1		
38		830105040	NUT	3		
39		833701280	HOLDER ASSEMBLY W/BRUSH	1		
40		833711150	BRUSH	2		