



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		830121221	COVER-Oil Pump	1		
2		831071250	COVER ASSEMBLY-Oil Pump	1		
3		831101521	PUMP ASSEMBLY-Oil	1		
4		831141050	GUIDE- O-Ring	1		
5		831161071	SCREEN-Strainer	1		
6	27	831191121	GASKET-Oil Pump	1		
7		831401390	STRAINER ASSEMBLY	1		
8		831411230	STRAINER	1		
9		836003490	BASE ASSEMBLY-Oil Filter (See Pa	1		
10		837101680	COOLER ASSEMBLY-Oil (See Pag	1		
11		835818181	PLATE-Caution	1		
12	22	830235130	CONNECTOR-Pipe	1		
13		830875111	RING-Retaining	1		
14	10	831914237	BOLT-Banjo	1		
15	10	838108200	BOLT-Oil Pump	5		
16		838108350	BOLT-Oil Pump	2		
17		838208300	BOLT-Oil Cooler	3		
18		839108251	BOLT	5		
19	10	839108401	BOLT	2		
20	10	839108602	BOLT	1		
21		839108651	BOLT-Strainer	2		
22		839108852	BOLT	2		
23	10	839908115	BOLT	3		
24	19	832910115	PLUG	3		
25	25	834402135	O-RING-Strainer	1		
26	12	835914110	WASHER-Sealing	3		
27	25	835119101	O-RING	8		