



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-		18900A 1	TRANSMISSION ASSEMBLY (1.5:	1	
-		18901A 1	TRANSMISSION ASSEMBLY (2.0:	1	
-		18902A 1	TRANSMISSION ASSEMBLY (2.5:	1	
1		813278	HOUSING	1	
2		813279	COVER	1	
3		813280	CAP-Vent	1	
4	13	813281	LOCKWASHER	12	
5	10	813282	SCREW	5	
6	10	813283	SCREW	1	
7	10	813284	SCREW	4	
8	10	813285	SCREW	2	
9	26	813286	SEAL-Oil	1	
10	10	813287	SCREW	4	
11		813288	PLATE-Retaining	1	
12	32	813289	HOSE	1	
13		813290	PLATE-Baffle	1	
14	17	813291	PIN-Dowel	2	
15	26	813292	SEAL-Oil	1	
16	13	813293	LOCKWASHER	7	
17	10	813294	SCREW	7	
18		813295	BLOCK ASSEMBLY-Control	1	
19	10	813296	SCREW	1	
20	12	813297	WASHER	1	
21		813298	LEVER-Shift	1	
22	11	813299	NUT	1	
23	87	813300	SWITCH-Neutral Safety	1	
24	27	813301	GASKET	1	
25	22	813302	PLUG	1	
26	12	813303	WASHER	1	
27	36	811940	CAP Kit	1	
28	35	815419	FILTER KIT-Fluid	1	
29	25	813407	O-RING	1	
30	25	813406	O-RING	1	
31		813305	DIPSTICK	1	
-		18900A 1	TRANSMISSION ASSEMBLY (1.5:	1	
-		18901A 1	TRANSMISSION ASSEMBLY (2.0:	1	
-		18902A 1	TRANSMISSION ASSEMBLY (2.5:	1	
32		813306	INPUT SHAFT	1	
33	31	813307	BEARING-Roller	4	
34	43	813308	GEAR	1	
35	12	813309	WASHER	2	