



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		836131280	GEAR-Injection Pump Drive	1	
2		837731480	PIPE-Oil	1	
3		837731371	PIPE-Oil	1	
4		830202730	PUMP ASSEMBLY-Injection	1	
4		830203830	PUMP ASSEMBLY-Injection	1	
4		830202732	PUMP ASSEMBLY-Injection	1	
5		NOTSERVIC	BODY-Pump	-	4
6		NOTSERVIC	GOVERNOR ASSEMBLY	-	4
7		833432060	BRACKET-Pump	1	
8		835011020	COVER-Timer	1	
9		835601630	PUMP ASSEMBLY- Fuel Feed	1	
10		836111630	FLANGE-Coupling	1	
12		830311210	BRACKET	1	
13		830812020	PIPE-Fuel Return	1	
14		830831320	PIPE-Fuel Feed	1	
14A		830831331	PIPE-Fuel Feed	1	
15	35	833001812	BASE AND FILTER ASSEMBLY-Fu	1	SEE "FUEL FILTER"
16		836001710	NOZZLE AND HOLDER SET	4	
17		836201461	HOLDER-Injector Nozzle	4	SEE "HOLDER - INJECTOR NOZ
18		836401510	NOZZLE-Injector	4	
19		836611140	GASKET-Nozzle-Copper	4	
20		836651110	ADAPTER-Nozzle	4	
21	25	836671070	RING-Packing-Rubber	4	
22	32	837111610	PIPE-Injector-#1	1	
23	32	837121600	PIPE-Injector-#2	1	
24	32	837131540	PIPE-Injector-#3	1	
25	32	837141570	PIPE-Injector-#4	1	
26	32	837811620	PIPE-Fuel	2	
27		837811981	PIPE-Fuel	1	
28		838061610	HOSE-Fuel	1	
29	32	838063030	HOSE-Fuel	1	
30		838031080	SEPARATOR ASSEMBLY-Water	1	SEE "WATER SEPARATOR"
31		835816020	PLATE-Caution	1	
32		839041930	CLIP-Pipe	6	
33		839042230	CLIP-Pipe	1	
34		839041170	CLIP-Pipe	1	
35	15	830111145	SHIM-Nozzle	4	
36	32	830231118	HOSE-Fuel	1	
37		830562139	TUBE	1	
38	10	831913101	BOLT-Banjo	2	
39		832910189	BOLT-Base	1	