



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		834914420	BRACKET-Pipe	1		
2		831001621	TURBOCHARGER ASSEMBLY	1	SEE "TURBOCHARGER (831001	
3		831721170	PIPE-Oil Outlet	1		
4		831071200	PIPE-Oil Outlet	1		
5		831351110	GASKET-Oil Outlet	1		
6	27	831351080	GASKET-Oil Outlet	1		
7	32	831711410	PIPE-Oil Outlet	1		
8	27	831791170	GASKET	1		
9		839041280	CLIP	1		
10		839041380	CLIP	1		
11		834921400	HOLDER-Clip	1		
12		830232061	HOSE-Oil	1		
13	32	830233363	HOSE-Air	1		
14		830233437	HOSE-Air	1		
15		831108160	BOLT	1		
16	10	832910261	BOLT	1		
17	10	838108200	BOLT	2		
18	10	839106202	BOLT	2		
19	10	839108162	BOLT	2		
20	10	839108351	BOLT	1		
21		839114252	BOLT	1		
22		830110080	NUT	1		
23		836008140	WASHER-Plain	1		
24	12	836010180	WASHER-Plain	1		
25	13	838008200	WASHER-Lock	1		
26		838010250	WASHER-Lock	1		
27	12	835410100	WASHER-Soft	2		
28		836602810	CLAMP	2		
29		836606510	CLAMP	2		
30		836975103	CLAMP	2		