



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	831851110	BODY-Vent Valve	2		
2		831881020	SEAT-Valve	2		
3		832681960	PIPE-Coolant	1		
4	22	832681550	CONNECTOR	3		
5	22	839041190	PIPE-Coolant	1		
6		831351110	GASKET-Oil Outlet	1		
7		839041230	CLIP	4		
8		831001821	TURBOCHARGER ASSEMBLY	1	SEE "TURBOCHARGER (831001	
9		831071231	PIPE-Oil Drain	1		
10	27	831351080	GASKET	1		
11		831711611	PIPE KIT-Oil Inlet	1		
12	27	831791170	GASKET-Turbo	1		
13		839041290	CLIP	1		
14		831531361	HOLDER-Clip	1		
15		830124344	BOLT-Banjo	1		
16		830124329	BOLT-Banjo	2		
17	10	831920114	BOLT-Banjo	2		
18	32	830154272	HOSE-Coolant	1		
19	32	830234338	HOSE	1		
20	32	830234212	HOSE-Coolant	1		
21	32	830233363	HOSE-Air	1		
22		830233437	HOSE-Air	1		
23	10	832910261	BOLT-Banjo	1		
24	10	838108200	BOLT	2		
25	10	839106202	BOLT	2		
26		836401820	CLAMP	6		
27	10	839108301	BOLT	1		
28	11	830108070	NUT	1		
29	12	836008180	WASHER-Flat	1		
30		836970103	CLAMP	2		
31		836960105	CLAMP	2		
32	19	832613060	PLUG	1		
33	12	835410100	WASHER-Sealing	2		
34	12	835420150	WASHER-Sealing	8		