



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		831001621	TURBOCHARGER ASSEMBLY	1		
1		831501140	ROTOR ASSEMBLY	1		
2		834999998	ROTOR-Turbine	1		
3	19	834999990	THR0WER-Oil	1		
4		831221050	BUSHING	1		
5		831241200	SEAL-Ring	1		
6		831241190	SEAL-Ring	1		
7		831241270	SEAL-Ring	1		
8		831171210	NUT-Lock	1		
9		831181100	IMPELLER-Blower	1		
10		831271090	PLATE-Black	1		
11		831311140	BEARING	2		
12		831431090	BEARING-Inboard Thrust	1		
13		831141130	CASE-Blower	1		
14		831451240	BOLT	6		
15		831231220	PLATE	6		
16		831111150	CASE-Turbine	1		
17		831451250	BOLT	6		
18		831441030	INSULATOR	1		
19		831211090	CASE-Bearing	1		
20		831321110	RING-Nozzle	3		
21		831361120	SCREW	4		
22		831361130	SCREW	3		
23		831411090	PROTECTOR-Heat	1		