



| Parts List | | | | | | |
|------------|-------|----------|--------------------------|-----|---------------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 77792A 2 | SWITCH PANEL ASSEMBLY | - | QUANTITIES: (77792A2) - 1, (777 | |
| -- | | 77792A 4 | SWITCH PANEL ASSEMBLY | - | QUANTITIES: (77792A2) - 0, (777 | |
| 1 | | 76426 | SWITCH PANEL | - | QUANTITIES: (77792A2) - 1, (777 | |
| 2 | | 55738A 1 | SWITCH ASSEMBLY, PUSH BU | - | QUANTITIES: (77792A2) - 2, (777 | |
| 3 | | NLA | HARNES | - | QUANTITIES: (77792A2) - 1, (777 | 3 |
| 4 | | 77642 | PLATE | - | QUANTITIES: (77792A2) - 1, (777 | |
| 5 | 10 | 69079 | SCREW (7/16") | - | QUANTITIES: (77792A2) - 3, (777 | |
| 6 | | NLA | WIRE ASSEMBLY (WHITE) | - | QUANTITIES: (77792A2) - 1, (777 | 3 |
| 7 | 10 | 38792 | SCREW (5/16") | - | QUANTITIES: (77792A2) - 1, (777 | |
| 8 | | NLA | BRACKET | - | QUANTITIES: (77792A2) - 1, (777 | 3 |
| 9 | 16 | 55422 | STUD (2") | - | QUANTITIES: (77792A2) - 2, (777 | |
| 10 | 12 | 24676 | WASHER | - | QUANTITIES: (77792A2) - 2, (777 | |
| 11 | 11 | 68219 | NUT | - | QUANTITIES: (77792A2) - 2, (777 | |
| 12 | | 68878A 6 | ALARM HORN | - | QUANTITIES: (77792A2) - 1, (777 | |
| 13 | | 68879 | COVER | - | QUANTITIES: (77792A2) - 1, (777 | |