



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		69392	SHIFT ACTUATOR, COMPLETE	1		2
2		NLA	ARMATURE	1		3
3		392-4960	SPRING SET, BRUSH	1		
4		392-4955	HEAD ASSEMBLY, COMMUTAT	1		
5		392-4956	BRUSH SET	1		
6		392-4962	THRU BOLT	2		
7		NLA	FIELD COIL ASSEMBLY	1		3
8		392-4951	CRANK ARM ASSEMBLY	1		
9		NLA	HEAD ASSEMBLY, DRIVE END	1		3
10		NLA	SCREW AND DISC PACKAGE	1		3
11		392-4652	GEAR AND GASKET PACKAGE	1		
12		392-4953	GASKET	1		
13		NLA	PLATE, CAM	2		3
14	11	20890	NUT	1		
15	10	47220	SCREW (3/8")	4		
16	84	62995A 1	HARNES ASSEMBLY (3 WIRE	1		
17		42528A 6	SWITCH PLATE	1	INCLUDES 1 PIECE OF REF. #12	