



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	1225	1529A26	FUEL TANK ASSEMBLY, COMPLE	1			
2	36	18962M	FILLER CAP ASSEMBLY	1			
3	10	25575	VENT SCREW	1			
4	12	49221	WASHER	1			
5	24	22227	SPRING	1			
6	11	28587	NUT	1			
7	27	41065	GASKET	1			
-		64841A 1	COVER ASSEMBLY, COMPLETE	1			
8		17792A 1	COVER ASSEMBLY (1/4-18 T/	1			
9	32	75239	TUBE (1/4-18 CONNECTOR A	1			
10		98542A 1	LENS ASSEMBLY	1			
--		28897A 2	FUEL GAUGE ASSEMBLY, CO	1			
12		20430	RETAINER	1			
13		28897A 1	INDICATOR AND FLOAT AS	1			
14		99274	FLOAT	1			
15	174	20426	RIVET	1			
16	10	62568	SCREW (5/16")	2			
17	27	28862	GASKET	1			
18		28860	FRAME	1			
19	11	28903	FASTENER	2			
20	10	20411	SCREW	4			
21	12	29070	WASHER	4			
22	37	13921	DECAL	1			