



| Parts List | | | | | | |
|------------|-------|--------|--------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 46017A | 1 EXHAUST WATER SHUTTER KIT | 1 | | |
| 1 | | 46005A | 3 TUBE ASSEMBLY, WATER SHL | 1 | | |
| 2 | 10 | 25612 | SCREW, DRIVE - TUBE ASSE | 4 | | |
| 3 | | 45586 | SHUTTER, WATER | 1 | | |
| 4 | | 47221 | BRACKET, SUPPORT - WATER | 2 | | |
| 5 | 10 | 37655 | SCREW, SUPPORT BRACKET | 4 | | |
| 6 | 11 | 45812 | NUT, SUPPORT BRACKET SCR | 4 | | |
| 7 | 54 | 32739 | CLAMP, EXHAUST HOSE | 4 | | |
| | | 35138A | 5 MARINE 110 AND 120 ALUMINUM | - | | |
| | | 58759A | 4 MARINE 140, 150 AND 160 ALUM | - | | |
| | | 39950A | 4 MARINE 110 AND 120 CAST IRON | - | | |
| | | 58759A | 4 MARINE 140, 150 AND 160 CAST | - | | |