



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		86047A14	AUDIO WARNING KIT	-	QUANTITIES: ?86047A14! -1, ?8	
-		86047A15	AUDIO WARNING KIT	-	QUANTITIES: ?86047A14! -0, ?8	
1		48952	SWITCH, WATER TEMPERATU	-	QUANTITIES: ?86047A14! -1, ?8	
1	87	86080	SWITCH, WATER TEMPERATU	-	QUANTITIES: ?86047A14! -0, ?8	
2	13	26996	LOCKWASHER	-	QUANTITIES: ?86047A14! -1, ?8	
3	11	45076	NUT	-	QUANTITIES: ?86047A14! -1, ?8	
4	87	805605A 1	SWITCH PRESSURE	-	QUANTITIES: ?86047A14! -1, ?8	
5	13	26996	LOCKWASHER	-	QUANTITIES: ?86047A14! -1, ?8	
6	11	45076	NUT	-	QUANTITIES: ?86047A14! -1, ?8	
7	22	52930	TEE	-	QUANTITIES: ?86047A14! -1, ?8	
8	22	38992	NIPPLE	-	QUANTITIES: ?86047A14! -1, ?8	
9	22	18021	REDUCER BRUSHING	-	QUANTITIES: ?86047A14! -1, ?8	
10		86047A11	BUZZER HOUSING (w/O BULL	-	QUANTITIES: ?86047A14! -1, ?8	
10		86047A16	BUZZER HOUSING (w/ BULLE	-	QUANTITIES: ?86047A14! -1, ?8	
11		86045	TIMER	-	QUANTITIES: ?86047A14! -1, ?8	
12		68878A 6	HORN	-	QUANTITIES: ?86047A14! -1, ?8	
13	10	69013	SCREW	-	QUANTITIES: ?86047A14! -2, ?8	
14	84	86044A11	WIRE ASSEMBLY (20")	-	QUANTITIES: ?86047A14! -1, ?8	
14	84	86044A 4	WIRE ASSEMBLY (36")	-	QUANTITIES: ?86047A14! -1, ?8	
14	84	13760A 6	WIRE ASSEMBLY (42" - W/INSI	-	QUANTITIES: ?86047A14! -1, ?8	