



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	87	63917A	3 SWITCH ASSEMBLY, COMP. - ST.	1		
-		76426A	4 SWITCH ASSEMBLY, COMP.	.1		
1		55642A	6 PANEL ASSEMBLY, IGNITION ST.	2		
1A		76426	PANEL, IGNITION START-STOP	1		
2		55738A	1 SWITCH ASSEMBLY, PUSH BUT	1		
2		55738A	1 SWITCH ASSEMBLY, PUSH BUT	.2		
3	87	65296	SWITCH ASSEMBLY, PUSH BUT	1		
4	23	63886	BUSHING, PUSH BUTTON SWIT	1		
5		55641	RETAINER, PUSH BUTTON SWIT	1		
5A		77642	RETAINER, PUSH BUTTON SWIT	1		
6	10	62568	SCREW, SWITCH RETAINER TO	4		
6	10	62568	SCREW, SWITCH RETAINER TO	.3		
7	16	55422	STUD, SWITCH PANEL TO DASH	4		
7	16	55422	STUD, SWITCH PANEL TO DASH	.2		
8	12	20878	WASHER, SWITCH PANEL STUD	4		
8	12	24676	WASHER, SWITCH PANEL STUD	.2		
9	11	27164	NUT, SWITCH PANEL STUD	4		
9	11	45076	NUT, SWITCH PANEL STUD	.2		
10	84	63889	HARNESS, SWITCH PANEL - STA	1		
10	84	63888	HARNESS, SWITCH PANEL - C/D	1		
10	84	78999A	1 HARNESS, SWITCH PANEL (4 WI	.1		
11	84	63594A	1 LEAD WIRE, C/D IGNITION (WHI	1		
12		55993	3 LEAD WIRE, C/D IGNITION (WHI	1		
13		75021	.1 STRAP, MOUNTING - PANEL TO	.1		