



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		33824	BRACKET, MOUNTING - FUSE BL			
2		36448	BRACKET, MOUNTING - FUSE BL			
3		55772	BRACKET, MOUNTING - FUSE BL			
4		34097	FUSE BLOCK, MOUNTING BRACK			
5	10	34123	SCREW, FUSE BLOCK TO MOUN			
6	13	26394	LOCKWASHER, FUSE BLOCK TO			
7	11	29236	NUT, FUSE BLOCK TO MOUNTIN			
5	10	47157	SCREW, FUSE BLOCK TO INSTR			
8	54	32780	CLAMP, STAINLESS STEEL - HAF			
9	54	22875	CLAMP, NYLON - HARNESS ATT			
9	54	23567	CLAMP, NYLON - HARNESS ATT			
9	54	46457	CLAMP, NYLON - HARNESS ATT			
9	54	22690	CLAMP, NYLON - HARNESS ATT			
9	54	24871	CLAMP, NYLON - HARNESS ATT			
10	54	46397	"J" CLIP, OPEN - HARNESS ATT			
11	10	29852	SCREW, WIRING HARNESS CLAI			
11	10	29762	SCREW, WIRING HARNESS CLAI			
11	10	33615	SCREW, WIRING HARNESS CLAI			
11	10	22793	SCREW, WIRING HARNESS CLAI			
12		22789	"C" WASHER, WIRING HARNESS			
13	11	20645	NUT, WIRING HARNESS CLAMP			
14	10	24231	SCREW, HARNESS LEAD WIRE H			
15	11	20645	NUT, HARNESS LEAD WIRE MAT			
16	23	37961	2 SLEEVE, HARNESS LEAD WIRE I			
16	23	32914	SLEEVE, HARNESS LEAD WIRE I			
17		33370	BINDER, WIRING HARNESS ANC			
17		33865	BINDER, WIRING HARNESS ANC			
18		32790	TERMINAL BLOCK, WIRING HAR			
19	10	28739	SCREW, WIRING HARNESS LE			
20	10	20644	SCREW, TERMINAL BLOCK TO B			
21	11	20645	NUT, TERMINAL BLOCK TO BOA			
22	10	33615	SCREW, WOOD - TERMINAL BLC			