



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47753A 3	TRANSMISSION ASSEMBLY, COM	1		
1		47754A 3	TRANSMISSION ASSEMBLY, COM	,1		
2	23	56572	BUSHING KIT, TRANSMISSION	1,1		
3		N.S.S.	BREATHER, TRANSMISSION H	1,1		
4			SPRING, POPPET - SHIFT LEV	1,1		
5			BALL, DETENT - SHIFT LEVER	1,1		
6		65120A 1	DIPSTICK AND TUBE, OIL LEV	1,1		
7		N.S.S.	SPRING AND VALVE ASSEMBL	1,1		
8			"O"RING, SPRINGANDVALVE	1,1		
9		N.S.S.	COVER VALVE	1,1		
10			GASKET, VALVE COVER	1,1		
11	10	28063	SCREW, VALVE COVER TO HOU	3,3		
12	13	26992	LOCKWASHER, VALVE COVER	3,3		
13		N.S.S.	STRAINER, OIL	1,1		
14		N.S.S.	TUBE, OIL STRAINER	1,1		
15	23	55558	BUSHING, OIL STRAINER TUB	1,1		
16		N.S.S.	BAFFLE, OIL	1,1		
17			GASKET, FORWARD/REVERSE	1,1		
18			RING, SNAP - CLUTCH SPRING	1,1		
19			WASHER, THRUST - PINION GI	1,1		
20		N.S.S.	PINION GEAR AND SHAFT ASS	1,		
20		N.S.S.	PINION GEAR AND SHAFT ASS	,1		
21			WASHER, THRUST - DRIVE GE	1,1		
22			KEY, DRIVE GEAR AND SHAFT	1,1		
23		N.S.S.	DRIVE GEAR AND SHAFT ASSE	1,		
23		N.S.S.	DRIVE GEAR AND SHAFT ASSE	,1		
24		N.S.S.	GEAR, FORWARD CLUTCH	1,		
24		N.S.S.	GEAR, FORWARD CLUTCH	,1		
25			RING SNAP-DRIVE GEAR AND	1,1		
26			KEY, FORWARD CLUTCH GEAR	1,		
26			KEY, FORWARD CLUTCH GEAR	,1		
27			RING, SEALING - DRIVE GEAR	2,2		
28		N.S.S.	GEAR, RING	1,		
28		N.S.S.	GEAR, RING	,1		
29			PLATE, PRESSURE - CLUTCH F	1,1		
30			PLATE, CLUTCH (OUTER) PART	AR,AR		
31			PLATE, CLUTCH (INNER) PART	AR,AR		
32			PLATE, PRESSURE - CLUTCH F	1,1		
33	24	56556	SPRING, CLUTCH PLATES	1,1		
34			RING, SEALING - FORWARD CL	1,1		