



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
-		39334A	2 RIDE-GUIDE DUAL STEERING KI	1,			
-		39334A	3 RIDE-GUIDE DUAL STEERING KI	,1			
1		39254	ADAPTOR, STEERING LINK RO	1,1			
2	23	35016	SPACER, STEERING LINK ROD	1,			
3	12	20086	WASHER, STEERING LINK ROI	1,			
4	11	20509	NUT, STEERING LINK ROD	1,			
4	11	55438	NUT, STEERING LINK ROD	,1			
5	10	24217	SCREW, ADAPTOR TO RIDE-GI	1,1			
5	10	66975	SCREW, ADAPTOR TO RIDE-GI	,1			
6	12	20086	WASHER, ADAPTOR SCREW	1,			
6	12	20086	WASHER, ADAPTOR SCREW	,2			
7	11	20509	NUT, ADAPTOR SCREW	1,			
7	11	55438	NUT, ADAPTOR SCREW	,1			
8		39336A	1 LINK ROD ASSEMBLY, STEERIII	1,			
8		66978A	1 LINK ROD ASSEMBLY, STEERII	,1			
9	11	22496	NUT, JAM - STEERING LINK RC	1,1			
10		39335A	1 EYE ASSEMBLY, STEERING - S	1,1			
11	16	32568	STUD, PIVOT - STEERING EYE	1,			
11	16	66979	SHD, PIVOT - STEERING EYE-	1,			
12	23	52070	SLEEVE, PIVOT STUD	1,1			
13	11	20509	NUT, PIVOT STUD	2,			
13	11	55438	NUT, PIVOT STUD	,2			
14	12	25909	WASHER, PIVOT STUD	3,			
14	12	25909	WASHER, PIVOT STUD	,4			
15	23	25915	BUSHING, PIVOT STUD	1,1			
16	24	20510	SPRING, PIVOT STUD	1,1			
17	12	29330	WASHER, NYLON - PIVOT STU	1,1			
18		29698	BALL, PIVOT STUD	1,1			
18A	18	45882	COTTER PIN, NUT LOCKING	,4			
19		30352A	1 COUPLER ASSEMBLY, EXTENSIC	AR,AR			
20	13	30381	LOCKWASHER, COUPLER ASS	2,2			
21		30353	ROD, LINK (16" EXTENSION)	AR,AR			
22		30351A	1 BAR ASSEMBLY (4" EXTENSION)	AR,AR			
23	13	30381	LOCKWASHER, EXTENSION B	1,1			