



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		34129A	STEERING HANDLE ASSEMBLY, COMPLETE	1	NLA PART IS SUPERSEDED BY	3
-		33405A 2	STEERING HANDLE ASSEMBLY, COMPLETE	1		
1		27763	GRIP, RUBBER - STEERING HANDLE	1		
2		33404	BODY AND SHAFT, STEERING HANDLE	1		
3		31001	INDICATOR, SPEED AND SHIFTER	1		
4	10	22290	SCREW, DRIVE - INDICATOR	1		
5	10	31002	SCREW, SET - SPEED AND SHIFTER	1		
6	23	30677	BUSHING, NYLON - STEERING HANDLE	1		
7		33405A 1	STEERING HANDLE ASSEMBLY, COMPLETE	1		
8	23	28100	BUSHING, NYLON - STEERING HANDLE	1		
9	12	20084	WASHER, STEERING HANDLE	1		
10	24	26703	SPRING, STEERING HANDLE	1		
11	14	26706	TAB WASHER, YOKE PIN HOIST	1		
12		30235	YOKE, STEERING HANDLE SHIFTER	1		
13	17	26862	PIN YOKE TO STEERING HANDLE	1		
14		33535A 1	THROTTLE CONTROL SHAFT	1		
15		35570	BRACKET, STEERING ARM	1		
16		30970	BOOT, RUBBER - THROTTLE CONTROL	1		
17	10	28663	SCREW, THROTTLE CONTROL	1		
18		34138	BRACKET, THROTTLE CONTROL	1		
19		31200	SOCKET, THROTTLE CONTROL	1		
20	23	31011	BUSHING, NYLON - THROTTLE CONTROL	1		
21	43	30703	GEAR, THROTTLE CONTROL SHIFTER	1		
22	17	22896	PIN, ROLL - GEAR TO THROTTLE CONTROL	1		
23	23	34136	BUSHING, NYLON - GEAR TO THROTTLE CONTROL	1		
24	43	34137	GEAR, VERTICAL - CONTROL BRACKET	1		
25	17	23928	PIN, ROLL - VERTICAL GEAR TO CONTROL BRACKET	1		
26	10	30720	SCREW, THROTTLE CONTROL	3		
27	13	26992	LOCKWASHER, THROTTLE CONTROL	3		
28		26711	PIVOT, STEERING HANDLE TO CONTROL BRACKET	2		
29	15	26707	SHIM, STEERING HANDLE PIVOT	2		
30	15	28485	SHIM, STEERING HANDLE TO CONTROL BRACKET	2		
31	10	28592	SCREW, STEERING HANDLE TO CONTROL BRACKET	2		
32		34135	LEVER, SHIFT CONTROL	1		
33		20980	KNOB, SHIFT CONTROL LEVER	1		
34	37	34204	DECAL, BOTTOM COWL	1		
35		33984	PLATE, CLAMP	1		
36		23026	DISC, FRICTION - CLAMP PLATE TO SWAY BRACKET	2		
37	10	26065	SCREW, CLAMP PLATE TO SWAY BRACKET	1		
38	13	21804	LOCKWASHER, CLAMP PLATE	1		