



10994

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		12022A34	TILLER HANDLE KIT	1	(Black)	
-		12022A35	TILLER HANDLE KIT	1	(Gray)	
34		12022A22	BRACKET ASSEMBLY, Steering	1	(Black)	
34		12022A23	BRACKET ASSEMBLY, Steering	1	(Gray)	
35	16	822320	STUD, (.3125 x 2.50)	2		
36		822263	SPACER, Steering Arm	1		
37	12	814806	WASHER, (.344 x .688 x .065)	2		
38	11	35814	NUT, (.312-24)	2		
39		12105	GROMMET	1		
40	84	12649A	HARNES ASSEMBLY	1		
41	87	88107A	SWITCH KIT, Key (With Keys)	1	(See Key Chart - Ignition Switch Fc	
NS	86	830865	CONNECTOR	AR	(Service Only)	
42	11	879755	NUT, Special - Black Nylon	1		
42	11	93543	NUT, Special	OPT	(Chrome Brass)	
43		12015A	COVER	1		
44	10	812832	SCREW, (#10-16 x .500)	6		
45	19	12014	PLUG	1		
46	87	11083A	SWITCH ASSEMBLY, Stop	1		
47		15920A54	LANYARD ASSEMBLY	1		
48		12044	RETAINER	1		
49	10	40003	SCREW, (M8 x 50)	1		
50	14	42981	TAB WASHER	1		
51	23	42992	BUSHING	2		
52		12021A	SHIFT LEVER	1	(Black)	
52		12021A	SHIFT LEVER	1	(Gray)	
53	12	815351	WASHER	1		
54	16	58152	STUD, (.375-24 x 1.125)	1		
55		98530	KNOB	1		
56		49563	SHIFT ROD	1		
57		48419	ROD END	1		
58	11	64015	NUT, (.250-20)	1		
59	23	26856	BUSHING	1		
60	12	29245	WASHER, (.281 x .500 x .060)	1		
61	18	25191	COTTER PIN	1		
62		12016A	DETENT/SPRING KIT	1		
63	87	14645A	TRIM SWITCH	1		
64		49440	NUT, (.468-32)	1		
65	84	86324A	CABLE ASSEMBLY (Yellow/Red)	1		
66	84	11149A	CABLE ASSEMBLY (3.250 Inche	1		
67		824930	BRACKET, Neutral Start Switch	1		