



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-		54119A 4	ROTARY RIDE-GUIDE TILT MOUNT	1		
1		48227 2	POST, TILT - STEERING WHEEL	1		
2	37	32710	STRIP, TRIM - TILT POST	1		
3	23	29097	BUSHING, NYLON - TILT POST	1		
4	10	54127	BOLT, STEERING WHEEL TO T	1		
5		48228 2	HOUSING, TILT POST MOUNTI	1		
6	10	48232	SCREW, MOUNTING HOUSING	2		
7	11	48238	NUT, MOUNTING HOUSING SC	2		
8	23	48237	BUSHING, NYLON - MOUNTING	2		
9	25	48182	QUAD RING, MOUNTING HOUSE	2		
10	16	29208	STUD, MOUNTING HOUSING T	4		
11	12	26825	WASHER, MOUNTING HOUSIN	4		
12	11	35814	NUT, MOUNTING HOUSING ST	4		
13		48224	LEVER, TILT ADJUSTING	1		
14	29	48235	PIN, DETENT - TILT ADJUSTIN	1		
15		48225 2	HOUSING, TILT ADJUSTING LE	1		
16	17	20009	PIN, DETENT - TILT ADJUSTIN	1		
17	24	35227	SPRING, TENSION - DETENT P	1		
18	19	20011	WELCH PLUG, DETENT PIN	1		
19	10	48240	SCREW, LEVER HOUSING TO P	2		
20	10	48240	SCREW, TENSION SPRING SP	1		
21	23	48233	SPACER, TENSION SPRING	1		
22	24	48234	SPRING, TENSION - TILT ADJU	1		
23		29220	SHAFT, STEERING WHEEL	1		
24	12	25897	WASHER, SHAFT TO GEAR RA	1		
25		54129	ADAPTOR, ROTARY STEERING	1		
26	10	29222	SCREW, STEERING ADAPTOR	2		
27	12	20086	WASHER, STEERING ADAPTOR	2		
28	11	49197	NUT, STEERING ADAPTOR SCI	2		
29	10	54126	SCREW, STEERING ADAPTOR	2		
30	23	25901	BUSHING, NYLON - STEERING	2		
31		54125	PINION, STEERING	1		
32	12	48241	WASHER, LOWER - STEERING	1		
33	11	23161	NUT, STEERING WHEEL BOLT	1		