



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		52777A	1 POWER STEERING KIT (SINGLE)	1		
1		52777A	2 POWER STEERING KIT (DUAL)	1		
2	23	52787	COLLAR, PLASTIC - CYLINDER	2,2		
3		52780	CYLINDER, BOOSTER (B-25-58)	1,1		
4	12	38742	WASHER, BOOSTER CYLINDER	4,4		
5	11	23161	NUT, BOOSTER CYLINDER SH-	1,1		
6	12	24889	WASHER, BOOSTER CYLINDER	1,1		
7	11	20220	NUT, BOOSTER CYLINDER ST-	1,1		
8		52779	VALVE, POWER STEERING (B-2	1,1		
9	12	35097	WASHER, POWER STEERING	1,1		
10	10	52781	SCREW, POWER STEERING VA	1,1		
11	10	26127	SCREW, SET - POWER STEER	1,1		
12	23	52796	SPACER, CABLE STOP	1,		
12	23	52796	SPACER, CABLE STOP	,2		
13		52795	STOP, STEERING CABLE	1,		
14		52786	ADAPTOR, POWER STEERING	1,		
14		55982	ADAPTOR, POWER STEERING	,1		
15	17	52798	PIN, CLEVIS - STEERING CABL	1,		
15	17	55951	PIN, CLEVIS - STEERING CABL	,1		
16	18	32857	COTTER PIN, CLEVIS PIN RET	1,1		
17	32	52782	TUBE, EXTENDING - POWER S	1,1		
18	32	52783	TUBE, RETRACTING - POWER	1,1		
19	23	36317	BUSHING, STEEL - POWER STI	2,2		
20	12	24889	WASHER, POWER STEERING	2,2		
21	11	36548	NUT, POWER STEERING CABL	1,1		
22		36368	HYDRAULIC PUMP ASSEMBLY	1,1		
23		38333	CAP, FILLER - HYDRAULIC PL	1,1		
24	32	52785	HOSE, RETURN - POWER STEI	1,1		
25	54	37295	CLAMP, RETURN HOSE	1,1		
26	32	52784	HOSE, PRESSURE - POWER S	1,1		
27		52788	BRACKET, ATTACHING - PRES	1,1		
28	10	21625	SCREW, ATTACHING BRACKET	1,1		
29	11	46887	NUT, ATTACHING BRACKET SC	1,1		
30	54	52789	CLAMP, PRESSURE AND RETL	1,1		
31	10	21625	SCREW, CLAMP TO ATTACHIN	1,1		
32	12	29245	WASHER, CLAMP SCREW	1,1		
33	11	46887	NUT, CLAMP SCREW	1,1		
34		52792A	1 CYLINDER ASSEMBLY, OUTER	1,1		
-	37	37359	DECAL, OUTER CYLINDER	1,1		
35		52794	COVER, INSPECTION - OUTER	2,2		