



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-		57288A 3	POWER STEERING KIT (STARBC	1		
-		57288A 4	POWER STEERING KIT (PORT M	1		
38	57	57298	"M" BELT, HYDRAULIC PUMP C	1,1		
39		56331A 1	PULLEY ASSEMBLY, CRANKSH	1,1		
40	10	52693	SCREW, PULLEY TO CRANKS	3,3		
41	13	35048	LOCKWASHER, PULLEY SCR	3,3		
42	12	20553	WASHER, PULLEY SCREW	3,3		
43		49181	PULLEY, HYDRAULIC PUMP	1,1		
44	11	25899	NUT, PULLEY TO HYDRAULIC I	1,1		
45		56313	BRACKET, HYDRAULIC PUMP I	1,1		
46	10	47651	SCREW, PUMP MOUNTING BR	2,2		
47	13	37272	LOCKWASHER, PUMP MOUNTI	2,2		
48	12	34567	WASHER, PUMP MOUNTING B	2,2		
49	10	37612	SCREW, HYDRAULIC PUMP TC	1,1		
50	10	34354	SCREW, HYDRAULIC PUMP TC	1,1		
51	13	35048	LOCKWASHER, HYDRAULIC PL	2,2		
52	23	57369	SPACER, HYDRAULIC PUMP SI	1,1		
53	32	49533	HOSE, OIL COOLER TO HYDRA	1,1		
54	54	37295	CLAMP, HOSE TO OIL COOLER	2,2		
55		57097	BRACE, HYDRAULIC PUMP	1,1		
56	10	27165	SCREW, BRACE TO HYDRAULI	1,1		
57	12	34664	WASHER, BRACE SCREW	1,1		
58	10	28464	SCREW, BRACE TO WATER PL	1,1		
59	13	37459	LOCKWASHER, BRACE SCREW	1,1		
60	12	34664	WASHER, BRACE SCREW	1,1		
61		49770	OIL COOLER	1,1		
62	22	37760	ELBOW, RETURN HOSE TO OIL	2,2		
63	32	57231	HOSE, OIL COOLER TO THERM	1,1		
64	32	57230	HOSE, OIL COOLER TO WATER	1,1		
65	54	32780	CLAMP, HOSE TO OIL COOLER	2,2		
66		56329	BRACKET, OIL COOLER	1,1		
67		56328	BRACKET, CLAMP - OIL COOLE	1,1		
68	10	21625	SCREW, CLAMP BRACKET TO I	2,2		
69	11	30506	NUT, CLAMP BRACKET SCREW	2,2		
70		57356	PLATE, MOUNTING - OIL COOL	1,1		
71	10	57357	SCREW, MOUNT PLATE TO EN	1,1		
72	12	34567	WASHER, MOUNT PLATE SCRI	2,2		
73	10	26065	SCREW, OIL COOLER BRACK	1,1		
74	12	26825	WASHER, OIL COOLER BRACK	2,2		
75	11	25594	NUT, OIL COOLER BRACKET SI	1,1		